



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		76575A 2	FUEL PUMP ASSEMBLY	1	
2	21	30430A 9	CHECK VALVE ASSEMBLY	1	
3		55278A 3	DIAPHRAM KIT	1	1,2,3
4			GASKET, CHECK VALVE TO	2	1,2,3
5			GASKET, FUEL PUMP	2	1,2,3
6		23004	RETAINER, CHECK VALVE	1	
7	10	68789	SCREW, RETAINER TO HOUSII	2	
8	10	35581	SCREW, PUMP MOUNTING (1 5/	3	
9	22	32802	PLUG, PIPE-FUEL PUMP	1	
10	32	71121	HOSE ASSEMBLY	1	FUEL PUMP TO EXHAUST PLATE
11	22	25885	ELBOW, DRIVE SHAFT HSG. ANI	2	UNITED STATES 4825249 AND I
11	22	25885	ELBOW, HOSE TO EXHAUST PLAT	1	UNITED STATES 4825248 AND I
12	32	71121	HOSE ASSEMBLY, GUEL PUMP T	1	UNITED STATES 4825248 AND I
12A	23	75920	SLEEVE, TELL TALE HOSE	1	UNITED STATES 4825248 AND I
13	54	68725	CLAMP, HOSE TO FUEL PUMP AP	4	UNITED STATES 4825248 AND I
14		69555	NOZZLE, TELL TALE-REAR SUPP	1	UNITED STATES 4825248 AND I
15	54	70705	CLAMP, TELL TALE NOZZLE	1	UNITED STATES 4825248 AND I
16	10	48408	SCREW, TELL TALE CLAMP	1	UNITED STATES 4825248 AND I
17	22	64705	FITTING, FUEL PUMP (INLET)	1	
18	32	70432	FUEL LINE, ADAPTOR TO FUEL F	1	
19	54	68424	CLAMP, FUEL LINE ATTACHING	10	
20	22	63187	FITTING, FUEL LINE TO ADDAPT	1	
21		22833	ADAPTOR, CHECK UNIT ( FUEL F	1	
22		23069	STEM, CHECK UNIT ADAPTOR	1	
23	25	20415	"O"RING, ADAPTOR STEM	1	1,2,3
24	24	23067	SPRING, ADAPTOR STEM	1	
25		30188	CUP WASHER, ADAPTOR	1	
26	10	76596	SCREW, ADAPTOR TO SUND AT	2	
28	32	70432	FUEL LINE, FUEL PUMP/FUEL FII	1	
29		76221	BASE, FUEL FILTER AND COVER	1	
30	10	22698	SCREW	1	FILTER BASE TO FRANSFER PA
31	12	34437	WASHER, FILTER BASE SCREW	1	
32	35	59072	FILTER, FUEL	1	1,2,3
33	25	47386	"O"RING, FILTER COVER	1	1,2,3
34		59071	COVER, FILTER	1	
35	10	37370	SCREW, FILTER COVER FASTEN	1	
36	27	25848	GASKET, FILTER COVER FASTEN	1	1,2,3
37	22	64704	FITTING, BASE	1	
38	32	70432	FULE LINE, BASE TO LOWER CA	1	
39	22	64706	TEE, LOWER CARBURETOR	1	
40	22	70432	FUEL LINE, CARBURETOR TO CA	1	