



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1440	1468A 1	CLAMP BRACKET ASSEMBLY	2,2		
2		28403A 3	THUMB SCREW ASSEMBLY	2,2		
3	12	28404	WASHER, THUMB SCREW	2,2		
4		28122	TUBE, TILT - CLAMP BRACKET T	1,1		
5	15	25600	SHIM, CLAMP BRACKET TILT TU	2,2		
6	11	25599	NUT, TILT TUBE FASTENING	2,2		
7		25606	CAP, PLASTIC - TILT TUBE	2,2		
8	23	20222	SPACER, CLAMP BRACKET STUC	1,1		
9	16	20221	STUD, CLAMP BRACKET	1,1		
10	13	26993	LOCKWASHER, CLAMP BRACKET	2,2		
11	11	20083	NUT, CLAMP BRACKET STUD	2,2		
12	17	29219A 1	TILT LOCK PIN ASSEMBLY	1,1		
13	32	28052	SLEEVE, RUBBER - TILT LOCK PI	1,1		
14	1446	1592A 1	SWIVEL BRACKET ASSEMBLY	1,1		
15	22	23612	FITTING, GREASE	1,1		
16	26	26209	OIL SEAL (SEE NOTE BELOW)	1,		
16	26	32911	OIL SEAL (SEE NOTE BELOW)	[,2]1		
17	24	28659	SPRING, COIL - SWIVEL BRACK	1,1		
18	17	28658	PIN, COIL SPRING MOUNTING	1,1		
19		29359	LUBRICAP, SWIVEL PIN GEAR FI	1,1		
20	23	28688	SPACER, RUBBER - COIL SPRING	2,2		
21	17	25598	PIN, REVERSE LOCK SPRING AT	1,1		
22	17	28211A 1	SWIVEL PIN AND TOP YOKE ASE	1,1		
23		28203	BUMPER, TOP YOKE	1,1		
24	10	28255	BOLT, TOP YOKE TO UPPER MO	2,2		
25	11	2218	NUT, TOP YOKE BOLT FASTENIN	2,2		
26	12	25176	WASHER, SWIVEL PIN - LOWER	1,1		
27	38	29537	SERIAL PLATE	1,1		
28	10	25612	SCREW, DRIVE - SERIAL PLATE	4,4		
29		28205	STRAP STOP, DRIVE SHAFT HOL	1,1		
30	10	28200	SCREW, STRAP STOP TO DRIVE	1,1		
31	11	25269	NUT, STRAP STOP FASTENING	1,1		
32		29317	YOKE, BOTTOM	1,1		
32		30197	YOKE, BOTTOM	,1		
33	11	28202	NUT, SWIVEL PIN RETAINING	1,1		
34		29484	ROD, PUSH - REVERSE LOCK	1,1		
35	24	26625	SPRING, REVERSE LOCK TENSIO	1,1		
36		26903A 4	REVERSE LOCK ASSEMBLY	1,1		
37		20208	SHAFT, REVERSE LOCK PIVOT	1,1		
38	12	20546	WASHER, PUSH ROD	2,2		
39	18	26191	COTTER PIN, PUSH ROD TO RE	1,1		