



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	179	1647A 2	COWL FRONT COVER ASSEMBL	1,1		
-		29560	BRACKET, COVER REINFORCE	1,1		
2	10	29226	SCREW, BRACKET TO FRONT	2,2		
3	13	26995	LOCKWASHER, BRACKET FAS	2,2		
4	11	26419	NUT, BRACKET FASTENING SC	2,2		
5		26183A	EMBLEM, FRONT COVER	1,1		
6	10	29552	SCREW, COVER FASTENING	1,1		
7	12	26162	WASHER, COVER FASTENING	1,1		
8	12	27897	WASHER, COVER FASTENING	1,1		
9		29345	BUMPER RUBER - FRONT COV	2,2		
10		29344	BLANKET, SOUNDK ABSORBIB	1,1		
11	181	1670A 2	WRAP AROUND COWL ASSEMBI	1,1		
12		21060	HANDLE, COWL LATCH	3,3		
13	53	21058	"E"RING, COWL LATCH HINGE	6,6		
14	17	21057	PIN, HINGE - COWL LATCH HAT	6,6		
15		25690	SWIVEL, COWL LATCH	3,3		
16		25691	HOOK, COWL LATCH FASTENIN	3,3		
17		26391	BLANKET, SOUND ABSORBING -	1,1		
--	92	25234	GLUE, ADHESIVE - BLANKET FAS	1,1		