



				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
1	167	1813A 2	BOTTOM COWL ASSEMBLY	1,1,1		
-	37	30862	DECAL, BOTTOM COWL - PORT	1,.		
-	37	31026	DECAL, BOTTOM COWL - STARB	1,.		
2		29229A 1	TRIM MOULDING ASSEMBLY	1,1,1		
3	10	29226	SCREW, DECORATIVE - MOULI	5,5,5		
4	12	24671	WASHER, FIBER - MOULDING	4,4,4		
5	11	29225	NUT, NYLON CAP - MOULDING	4,4,4		
6	11	26419	NUT, BRASS - MOULDING FAS	1,1,1		
7		23760	BAFFLE, BOTTOM COWL	1,1,1		
8	10	21106	SCREW, BAFFLE TO BOTTOM CC	3,3,3		
9		30768	BRACKET, RECTIFIER MOUNTIN	1,1,1		
10	10	21091	SCREW, BRACKET TO BOTTOM	2,2,2		
11	10	22956	SCREW, BRACKET TO BOTTOM	1,1,1		
12	11	20184	NUT, RECTIFIER BRACKET MOU	3,3,3		
13	27	26197	GASKET, POWERHEAD TO BOT1	1,1,1		
14	10	21504	SCREW, BOTTOM COWL TO DRI	1,1,1		
15		20557	BRACKET, CABLE END ANCHOR	2,2,2		
16	10	29200	SCREW, ANCHOR BRACKET TO	4,4,4		
17		29532	LEVER, THROTTLE CONTROL	1,1,1		
18		30612	LEVER, SHIFT CONTROL	1,1,1		
19	23	29529	BUSHING, THROTTLE AND SHIF	2,2,2		
20	10	26632	SCREW, THROTTLE AND SHIF	2,2,2		
21	12	29395	WASHER, THROTTLE AND SHIF	4,4,4		
22	17	30978A 1	PIN ASSEMBLY, CLEVIS YOKE	2,2,2		
23	17	23928	ROLL PIN, CLEVIS YOKE PIN	2,2,2		
24	10	20584	SCREW, CLEVIS PIN FASTENING	2,2,2		
25	13	29402	WASHER, WAVE - PIN FASTENIN	2,2,2		
26	11	29488	NUT, PIN FASTENING SCREW	2,2,2		
27		30789A 1	SHIFT SHAFT ASSEMBLY, UPPEf	1,1,1		
28		27714	ROD (ELEEVE), SHIFT CONTROL	1,1,1		
29	11	25168	NUT, SHIFT SHAFT END ADJUST	1,1,1		
30		25134	ROD, LINK - SHIFT SHAFT END	1,1,1		
31	18	25191	COTTER PIN, LINK ROD TO SHIF	2,2,2		
32	12	20583	WASHER, LINK ROD	2,2,2		
33	24	30621	SPRING, DETENT	1,1,1		
34	10	20776	SCREW, DETENT SPRING TO BC	1,1,1		
35	12	20346	WASHER, DETENT SPRING SCR	1,1,1		
36	11	20184	NUT, DETENT SPRING SCREW	1,1,1		
--	19	31469	PLUG, HOLE - BOTTOM COWL (T	1,1,1		