



Parts List					
Ref	Class	Part	Description	Qty	Footnote
-	1623	1780A 3	GEAR HOUSING ASSEMBLY, CO	1	
-	1623	1780A 2	GEAR HOUSING ASSEMBLY, CO	1	
1	1623	1780A 1	GEAR HOUSING ASSEMBLY (SI	1	
53		36288	CAM, SHIFT	1	
54		30625	FOLLOWER, CAM	1	
55		30624	SLIDE, CROSS PIN	1	
56	24	30622	SPRING, COMPRESSION - CAM	1	
57	15	30923A 1	SHIM, BEARING OUTER RACE	AR	
--	43	30938A 1	FORWARD GEAR ASSEMBLY, (1	
58	43	30938	FORWARD GEAR ASSEMBLY	1	
59	31	30895	BEARING, ROLLER - FORWARD	1	
60	31	30894A 1	TAPERED ROLLER BEARING	1	
61	31	31092	CUP, OUTER - TAPER ROLL	1	
62		30941	RATCHET, SLIDING CLUTCH	1	
63	17	30632	PIN, CROSS - RATCHET TO PR	1	
64	24	30893	SPRING, RETAINING - CROSS	1	
65	44	30944	SHAFT, PROPELLER	1	
--	43	30937A 1	REVERSE GEAR ASSEMBLY, C	1	
66	43	30937	REVERSE GEAR ASSEMBLY	1	
67	30	30548	BEARING, BALL - REVERSE	1	
68	15	29955A 1	SHIM, THRUST WASHER TO G	AR	
69	12	30633	WASHER, THRUST - BEARING	1	
70	25	29976	"O" RING, BEARING CARRIER	1	
71		30579A 1	BEARING CARRIER ASSEMBLY	1	
72	31	30616	BEARING, ROLLER - BEARIN	2	
73	26	30550	OIL SEAL, BEARING CARRIER	2	
74	28	30281	KEY, LOCATING - BEARING CA	1	
75	12	29957	WASHER, GEAR HOUSING CO	1	
76		31037	COVER, GEAR HOUSING	1	
77	12	31013	WASHER, THRUST - BEARING C	1	
78		30581A 1	THRUST HUB AND WASHER AS	1	
79	12	29590	WASHER, CUPPED - THRUST	1	
80	48	31072A 2	PROPELLER ASSEMBLY, COMPL	1	
81	12	30967	WASHER, SPLINED - PROPELLE	1	
82	14	30963	TAB WASHER, PROPELLER NUT	1	
83	11	29594	NUT, PROPELLER	1	
84		31237	WATER PICKUP, GEAR HOUSIN	1	
85	27	30557	GASKET, WATER PICKUP TO GE	1	
86	10	30559	SCREW, WATER PICKUP TO GE	1	
87	13	26393	LOCKWASHER, WATER PICKUP	1	
88	10	20205	SCREW, GEAR HOUSING TO DR	1	