



| | | | | Parts List | | |
|-----|-------|----------|------------------------------------|------------|---------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | 179 | 1647A 3 | COWL FRONT COVER ASSEMBLY | 1, | | |
| 1 | 184 | 2004A 2 | COWL FRONT COVER ASSEMBLY | ,1,1 | | |
| 2 | | 26183A 5 | EMBLEM, FRONT COVER | 1,1,1 | | |
| 3 | 10 | 29226 | SCREW, BRACKET TO FRONT | 2,2,2 | | |
| 4 | 13 | 26995 | LOCKWASHER, BRACKET FASTENING | 2,2,2 | | |
| 5 | 11 | 26419 | NUT, BRACKET FASTENING SCREW | 2,2,2 | | |
| 6 | | 29345 | BUMPER, RUBBER - FRONT COVER | 2, | | |
| 6 | | 32273 | BUMPER, RUBBER - FRONT COVER | ,2,2 | | |
| 7 | | 32361 | KNOB, COWL FRONT COVER FASTENING | 1, | | |
| 7 | | 32269 | KNOB, COWL FRONT COVER FASTENING | ,1,1 | | |
| 8 | 12 | 30771 | WASHER, COVER FASTENING | 1,1,1 | | |
| 9 | 12 | 26825 | WASHER, COVER FASTENING | 2,2,2 | | |
| 10 | 24 | 30772 | SPRING, TENSION - FASTENING | 1, | | |
| 10 | 24 | 32271 | SPRING, TENSION - FASTENING | ,1,1 | | |
| 11 | 17 | 29077 | ROLL PIN, TENSION SPRING TENSION | 1,1,1 | | |
| 12 | | 31089 | STRIP, SOUND ABSORBING | 2,2,2 | | |
| 13 | 181 | 1670A 4 | WRAP AROUND COWL ASSEMBLY | 1, | | |
| 13 | 198 | 2006A 2 | WRAP AROUND COWL ASSEMBLY | ,1,1 | | |
| 14 | | 30412 | HANDLE, COWL LATCH | 3,3,3 | | |
| 15 | 53 | 21058 | "E" RING, COWL LATCH HINGE | 6,6,6 | | |
| 16 | 17 | 21057 | PIN, HINGE - COWL LATCH HANDLE | 6,6,6 | | |
| 17 | | 30414 | SWIVEL, COWL LATCH | 3,3,3 | | |
| 18 | | 30413 | HOOK, COWL LATCH FASTENING | 3,3,3 | | |
| 19 | | 26391 | BLANKET, SOUND ABSORBING | 1,1,1 | | |
| 20 | 37 | 32266 | DECAL, WRAP AROUND COWL | ,1,1 | | |
| 21 | 37 | 32265 | DECAL, WRAP AROUND COWL | ,1,1 | | |
| -- | 92 | 25234 | GLUE, ADHESIVE - BLANKET FASTENING | 1,1,1 | | |
| -- | 92 | 27109 | ADHESIVE COMPOUND (3-1/2 OZ) | 1,1,1 | | |