



15169

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
-	1667	9011A 7	GEAR HOUSING ASSEMBLY, Lon	1		
-	1667	9011A13	GEAR HOUSING ASSEMBLY, X-L	1		
-	1667	9011A 9	GEAR HOUSING ASSEMBLY, Lon	1		
-	1667	9011A14	GEAR HOUSING ASSEMBLY, X-L	1		
-	1667	9011A31	GEAR HOUSING ASSEMBLY, Lon	1		
1	1667	9011A 6	GEAR HOUSING ASSEMBLY, BI	1		
1	1667	9011A 8	GEAR HOUSING ASSEMBLY, G	1		
1	1667	9011A29	GEAR HOUSING ASSEMBLY, O	1		
41	15	44491A 1	SHIM SET	1		
42	31	30894A 1	BEARING SET, Cup And Cone	1		
43	43	12634A 2	FORWARD GEAR ASSEMBLY	1		
44	31	30895	ROLLER BEARING	1		
45		12239A 1	CAM FOLLOWER ASSEMBLY	1		
45A	30	44530	BALL	3		
46	24	30622	SPRING	1		
47	52	12777	RATCHET	1		
48	17	30632	PIN, Cross, Clutch	1		
49	24	30893	SPRING, Cross Pin Retainer	1		
50	44	12238T	PROPELLER SHAFT	1		
51	43	12635	REVERSE GEAR	1		
52		12596A 2	BEARING CARRIER ASSEMBLY	1		
53	25	97386	O-RING	1		1,2
54	31	30956	ROLLER BEARING	1		
55	26	76868	SEAL, Inner	1		2
56	26	70081	OIL SEAL, Outer	1		2
57	31	12578	ROLLER BEARING	1		
58	12	12577	THRUST WASHER	1		
59	31	12576	THRUST BEARING	1		
60	10	40003 54	SCREW, (M8 x 30), Bearing Carri	2		
61	12	40023 17	WASHER, Bearing Carrier Screw	2		
62		13191A 1	THRUST HUB AND WASHER AS:	1		
63	14	31210	TAB WASHER, Propeller	1		
64	11	52707A 1	NUT, Propeller	1		
-	36	43035A 1	SEAL KIT	1		
-	27	43004A86	GASKET SET	1		