



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	472	9001A 2	CRANKSHAFT ASSEMBLY	1	
2	30	43011	BALL BEARING, CRANKSHAFT	1	
3	53	93412	RETAINING RING, BALL BEARIII	1	
4		54196A 6	CARRIER ASSEMBLY, SEAL	1	
5		65800	SEAL, CARRIER	1	10
6	28	91800	KEY, DRIVE	2	
7	43	43019A 1	DRIVER GEAR	1	
8	39	42079A 4	RING ASSEMBLY, SEALING	1	
9		42943A 1	ROLLER BEARING ASSEMBLY	2	
10	777	9009A 5	PISTON ASSEMBLY (STANDARD	3	
10	777	9009A 6	PISTON ASSEMBLY (.015 O.S.)	AR	7
10	777	9009A 7	PISTON ASSEMBLY (.030 O.S.)	AR	7
11	40	52035	LOCK RING	6	
12	39	96170A12	PISTON RING ASSEMBLY (STA	1	
12	39	96170A 3	PISTON RING ASSEMBLY (.015	AR	7
12	39	96170A 4	PISTON RING ASSEMBLY (.030	AR	7
13	638	9002A 2	CONNECTING ROD ASSEMBLY	3	
14	12	47247	WASHER	6	
15	29	88258	NEEDLE BEARING	87	
16	10	43813	SCREW	6	
17	31	43012A 1	ROLLER BEARING ASSEMBLY	3	
18	31	43013A 1	ROLLER BEARING ASSEMBLY	1	
19	26	43993	OIL SEAL	1	
20	25	64067	"O" RING	1	10
-	27	43004A86	GASKET SET		