



15152

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		42965A 1	BRACKET ASSEMBLY, Cowl Seal.	1		
1		42965A 2	BRACKET ASSEMBLY, Cowl Seal.	1		
1		42965A 3	BRACKET ASSEMBLY, Cowl Seal.	1		
2		18306 1	SEAL, Bracket, Black, Gray	2		
2		19386 1	SEAL, Bracket, Oyster	2		
3		42935	SEAL	1		
4		42908	RESTRAINT	1		
5	10	40001 5	SCREW, (M5 x 10), Restraint	1		
6	12	43423	WASHER, Restraint Screw	1		
7		42907	CONNECTOR, Tell Tale, Black, Gr.	1		
7		42907 1	CONNECTOR, Tell Tale, Oyster	1		
8	32	99129 76	TUBING, Tell Tale	1		
9	54	90077	STA STRAP	1		
10		93264 2	HOUSING, Hinge	2		
11	10	40095 60	SCREW, Housing	4		
12	12	93853	WASHER, Housing Screw	8		
13	12	53705	WASHER, Housing Screw	8		
14	25	88033	GROMMET, Housing Screw	4		
15	23	14395	BUSHING, Housing Screw	4		
16	10	40001 23	SCREW, (M5 x 30), Housing To Br	2		
17	12	43423	WASHER, Housing Screw	2		
18		42952T	BRACKET, Support, Front, Black	1		
18		42952T 6	BRACKET, Support, Front, Gray	1		
18		42952T10	BRACKET, Support, Front, Oyster	1		
19		67260	SEAL, Control Cables	1		
20	25	67272	GROMMET, Bracket	2		
21		88621	RETAINER, Control Cables, Non Pi	1		
21		99447T	RETAINER, Control Cables, Power	1		
22	10	40057109	SCREW, (M5 x 25), Retainer	2		
23	10	40111 35	SCREW, Retainer	2		
24	12	93853	WASHER, Bracket Screw	4		
25	12	53705	WASHER, Bracket Screw	4		
26	25	88033	GROMMET, Bracket	2		
27	23	14395	BUSHING, Bracket Screw	2		