



15163

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	472	9001A 3	CRANKSHAFT ASSEMBLY	1		5
2	30	43011	BALL BEARING, Lower	1		5
3		78661 1	WEAR SLEEVE	1		5
4	25	35126	O-RING	1		5
5	39	818412A 4	RING ASSEMBLY	1		5
6	28	91800	KEY, Woodruff	2		5
7	43	43019A 1	DRIVER GEAR	1		5
8	31	43013A 1	ROLLER BEARING ASSEMBLY, U	1		5
9	26	43993	SEAL, Oil	1		5
10	25	823683	O-RING	1		5,2
11		42943A 1	ROLLER BEARING ASSEMBLY	2		5
12	777	815965A 4	PISTON ASSEMBLY, Standard	3		5
12	777	815965A 5	PISTON ASSEMBLY (.015 Oversiz	AR	(As Required)	
12	777	815965A 6	PISTON ASSEMBLY (.030 Oversiz	AR	(As Required)	
13	40	52035	RING	6		5
14	39	96170A12	PISTON RING ASSEMBLY, Stan	1		5
14	39	96170A 3	PISTON RING ASSEMBLY (.015	AR	(As Required)	
14	39	96170A 4	PISTON RING ASSEMBLY (.030	AR	(As Required)	
15	646	818846A 3	CONNECTING ROD ASSEMBLY	3		5
16	12	812876	WASHER	6		5
17	29	818391	NEEDLE BEARING	87		5
18	10	94320	SCREW, (.375-24 x 1.250)	6		5
19	31	816567A 1	ROLLER BEARING ASSEMBLY	3		5
-		13589T93	POWERHEAD ASSEMBLY COMPI	1		
-		13600T93	POWERHEAD ASSEMBLY COMPI	1		
-		15081T96	POWERHEAD ASSEMBLY COMPI	1		