



4657

Parts List

| Ref | Class | Part | Description | Qty | Comment | Footnote |
|-----|-------|-----------|------------------------------|-----|------------------------------|----------|
| 1 | 19 | 45307 | PLUG, (Yellow) | 1 | | |
| 2 | | 812777T 1 | COVER ASSEMBLY | 1 | | |
| 3 | 11 | 42979 | NUT, (M16) | 1 | | |
| 4 | 12 | 68229 | WASHER | 1 | | |
| 5 | 261 | 878226T10 | FLYWHEEL ASSEMBLY | 1 | (Electric-Oil Injection) | |
| 5 | 261 | 878226T16 | FLYWHEEL ASSEMBLY | 1 | (Electric-Non Oil Injection) | |
| 6 | 261 | 878226T 8 | FLYWHEEL ASSEMBLY | 1 | (Manual) | |
| 7 | 398 | 832075A21 | STATOR ASSEMBLY | 1 | (Electric) | |
| 7 | 398 | 832074A11 | STATOR ASSEMBLY | 1 | (Manual) | |
| 8 | 10 | 40139 25 | SCREW, (M5 x 25) | 4 | | |
| 9 | | 854512T | TRIGGER | 1 | | |
| 10 | | 56762 | CABLE TIE, (4.00 Inches) | 3 | | |
| 11 | | 93254 | SWIVEL BASE | 1 | | |
| 12 | | 93421 | SWIVEL BALL | 1 | | |
| 13 | 50 | 66015T 1 | STARTER MOTOR | 1 | | |
| 13 | 50 | 893891T | STARTER MOTOR | 1 | | |
| 14 | | 56703 | COLLAR | 2 | | |
| 15 | 17 | 68402 | PIN, (.250 x 1.13) | 2 | | |
| 16 | 84 | 93388A 1 | CABLE ASSEMBLY, Black | 1 | | |
| 17 | 10 | 69035 | SCREW AND LOCKWASHER, (.250) | 1 | | |
| 18 | 84 | 93388A 8 | CABLE ASSEMBLY, (Black) | 1 | | |
| 19 | 13 | 26392 | LOCKWASHER, (.250) | 1 | | |
| 20 | 11 | 64015 | NUT, (.250-20) | 1 | | |
| 21 | 37 | 827282 2 | DECAL, Warning, High Voltage | 1 | (Electric) | |
| 22 | | 13541 | PLUG, Male | 2 | (Manual) | |
| 23 | 37 | 881865 | DECAL, Caution-Start in Gear | 1 | (Start In Gear) (Electric) | |