



A=TO FUEL PUMP

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	1277	828361A 3	OIL TANK ASSEMBLY	1		1
2	36	821902A 1	COVER ASSEMBLY	1		
3	27	822061 2	GASKET	1		
4		824612	LATCH	1		
5	24	824611	SPRING	1		
6	10	40056 66	SCREW	2		
7	12	27882	WASHER	2		
8	17	822059	GROOVE PIN	1		
8	17	825259	ROLL PIN (.093 X 1.250)	1		
9		19299A 1	VENT ASSEMBLY	1		
10	21	64871	VALVE	1		
11	10	40106 30	SCREW	1		
12	12	40023 16	WASHER	1		
13	25	42117	GROMMET	1		
14	23	42116	BUSHING	1		
15		99161	BOOT	1		
16		42888	BASE	1		
17	10	821550 50	SCREW	2		
18	87	12886A 6	SWITCH ASSEMBLY	1		
19	10	58376	SCREW	1		
20	12	72761	WASHER	1		
21	43	43020 4	DRIVEN GEAR	1		
22	25	62705	O-RING	2		4
23		17335A 3	ADAPTOR ASSEMBLY	1		
24	23	17597	BUSHING	1		
25	23	17596	JOURNAL BUSHING	1		
26		42959A 2	OIL PUMP	1		
27	10	821045 40	SCREW	2		
28	32	823813 29	TUBING (5-1/2 IN.)	1		
29	32	823814 55	TUBING (11 IN.)	1		1
30	54	816311	STA-STRAP	AR	(8 IN.)	11
30		69355	STA-STRAP	AR	(5-1/2 IN.)	11
.	27	43004A90	GASKET SET	1		