



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	1655	7333A25	GEAR HOUSING ASSEMBLY	1		
-	1655	7333A41	GEAR HOUSING ASSEMBLY	1		
1	1655	7333A23	GEAR HOUSING ASSEMBLY	1		
1	1655	7333A43	GEAR HOUSING ASSEMBLY	1		
48		76039	SHIFT CAM	1		
49		44532A 1	CAM FOLLOWER	1		
51	24	30622	SPRING, COMPRESSION - CAM	1		
52	15	30923A 1	SHIM, BEARING OUTER RACE	AR	(.002-3-5-10)	4
53	31	30894A 1	TAPERED ROLLER BEARING A	1		
54	43	75314A 2	FORWARD GEAR	1		
55	31	30895	ROLLER BEARING, FORWARD	1		
56	52	34239	RATCHET, SLIDING CLUTCH	1		
57	17	30632	CROSS PIN, RATCHET TO PRO	1		
58	24	30893	SPRING, RETAINING - CROSS F	1		
59	44	93003	PROPELLER SHAFT	1		
60	43	77562	REVERSE GEAR	1		
61	12	76358	THRUST WASHER	1	BEARING CARRIER TO GEAR H	
62	25	29976	"O" RING, BEARING CARRIER	1		2,7
63		41529A 1	BEARING CARRIER ASSEMBLY	1		
64	22	98727	GREASE FITTING	2		
65	31	30956	ROLLER BEARING, BEARING	1		
66	26	76868	OIL SEAL, BEARING CARRIER	1		7
67	26	70081	OIL SEAL, BEARING CARRIER	1		7
68	28	30281	KEY, LOCATING - BEARING CARRIER	1		
69	14	52700	TAB WASHER, GEAR HOUSING	1		
70		52699	COVER, GEAR HOUSING	1		
71		31640A 1	TRIM TAB, GEAR HOUSING	1		
72	10	66024	SCREW, TRIM TAB TO GEAR H	1		
73	12	45176	WASHER, DRIVE SHAFT HOUSING	2		
74	11	34933	NUT, DRIVE SHAFT HOUSING	2		
75	10	65210	SCREW, GEAR HOUSING (1")	1		
76		75282A 1	THRUST HUB	1		
77	14	31210	TAB WASHER, PROPELLER NUT	1		
78	11	52707A 1	PROPELLER NUT	1		