



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		43289A 2	PLATE ASSEMBLY, EXHAUST EX	1		
2	23	27132	BUSHING, NYLON-EXHAUST E	1		
3	17	23784	DOWEL PIN, EXHAUST EXTEN	2		
4		37918	SEAL, EXHAUST EXTENSION F	1		
5		99358	STRIP, RETAINING - EXHAUST	1		
6	10	37571	SCREW	5	SEAL AND RETAINING STRIP TI	
7	27	69238	GASKET, POWERHEAD	1		2
8	10	66023	SCREW, ADAPTOR PLATE TO HO	2		
9	10	66023	SCREW	7	HOUSING PLATE TO DRIVE SHA	
10	27	66102	GASKET, DRIVE SHAFT HOUSINI	1		2
11	26	60898	SEAL, DRIVE SHAFT HOUSING P	1		
12		43290A 4	PLATE ASSEMBLY, DRIVE SHAF	1		
13	26	38970	SEAL, RUBBER - WATER INLET	1		2
14	17	23784	DOWEL PIN, DRIVE SHAFT HOU:	2		
15		99698	EXHAUST TUBE	1		
16	10	65414	SCREW	4	EXHAUST TUBE TO DRIVE SHA	