



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		73434A 5	FUEL PUMP ASSEMBLY	1		
2	21	30430A13	CHECK VALVE ASSEMBLY	1		
3		55278A 5	DIAPHRAGM ASSEMBLY	1		2
4			GASKET, CHECK VALVE	2		2
5			GASKET, FUEL PUMP	2		2
6	24	86207	SPRING	1		
7		86252	CAP	1		
8		23004	RETAINER, CHECK VALVE	1		
9	10	43725	SCREW, CHECK VALVE TO FUE	2		
10	35	73532	FUEL FILTER	1		2
11	25	35480	"O"RING, COVER TO FUEL PUM	1		2
12	35	14805A 2	COVER, FUEL FILTER	1		
13	10	37370	SCREW, COVER TO FUEL PUM	1		
14	27	25848	GASKET, COVER SCREW	1		2
15	10	70939	SCREW, FUEL PUMP TO UPPE	2	(1-7/8")	
15	10	69067	SCREW, FUEL PUMP TO UPPE	2	(1-3/8")	
16	22	64705	FITTING, FUEL PUMP ,W/O INL	1		
17	32	99127109	FUEL LINE, TEE TO FUEL PUMP(	1	W/O INLINE FILTER	
18	22	73318	TEE, FUEL LINE	1		
19	32	99127109	FUEL LINE	2	CARBURETOR TO TEE TO CARI	
20		73498	CLAMP, FUEL LINE	8		
21	32	99127109	FUEL LINE, ADAPTOR TO FUEL F	1		
22	22	63187	FITTING, FUEL LINE TO ADAPTO	1		
23		30186	ADAPTOR, CHECK UNIT	1		
24		30187	STEM, CHECK UNIT ADAPTOR	1		
25	25	20415	"O"RING,ADAPTOR STEM	1		2
26	24	30189	SPRING, ADAPTOR STEM	1		
27		30188	CUP WASHER, ADAPTOR	1		
28	10	36154	SCREW, ADAPTOR TO BOTTOM	2		
29	11	36069	NUT, ADAPTOR SCREW	2		
30	22	64704	FITTING (90 DEG. )WITH INLINE	1		
31	32	99127109	FUEL LINE WITH INLINE FILTER	1		
32	35	13430	FUEL FILTER WITH INLINE FILTE	1		