



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	3401	8718A	TRANSOM BRACKET (STARBOARD)	1		
2	3400	8716A	TRANSOM BRACKET (PORT) -ME	1		
1	3401	8718A	TRANSOM BRACKET (STARBOARD)	1		
2	3400	8716A	TRANSOM BRACKET (PORT) MAI	1		
3	22	98727	GREASE FITTING, PORT TRAN	1		
4	17	49930A	TILT PIN ASSEMBLY (NON-POWE	1		
5		99170A	TILT TUBE	1		
6	11	34862	NUT, TILT TUBE (1"-14)	1		
7	25	45711	"O" RING, TILT TUBE	2		
8	13	88750	WAVE WASHER, TILT TUBE	2		
9	11	56041	NUT, TILT TUBE (7/8-14)	1		
10	10	67755	BOLT, TRANSOM BRACKET TO T	4		
11	12	28421	WASHER, TRANSOM BRACKET	4		
12	11	91962	NUT, TRANSOM BRACKET BOLT	4		
13		99629A	LEVER ASSEMBLY, TILT LOCK	1		
14	13	99611	WAVE WASHER, TILT LEVER	1		
15	23	65830	BUSHING, TILT LEVER	2		
16		99633	KNOB, TILT LOCK LEVER	1		
17	17	99615	GROOVE PIN	1		
18	24	99622	SPRING	1		
19	17	99604	GROOVE PIN	1		
20	10	96930A	BOLT ASSEMBLY, TILT LOCK-PO	1		
21	11	23161	NUT, BOLT -POWER TRIM	1		