



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	2182	7927A 8	FRONT COVER ASSEMBLY, MER	1	1
2		56849	KNOB FRONT COVER (MERCUF	1	
3	12	30771	WASHER, COVER KNOB (RUBE	1	
4	12	75246	WASHER, COVER KNOB (STEE	2	
5	24	30772	SPRING, TENSION-COVER KNC	1	
6	17	29077	ROLL PIN, TENSION SPRING T	1	
7		47341A 1	ROPE, STARTER (MERCURY)	1	
8		94923	SEAL, SOUND ABSORBING (ME	2	
9		38674	BLANKET, SOUND ABSORBING	1	
10	2119	3248A16	WRAP AROUND COWL ASSEMBL	1	1
11		46785A 1	COWL LATCH ASSEMBLY (MEF	2	
12		30413	HOOK, COWL LATCH (MERCUF	2	
1	2163	6393A 6	FRONT COVER, (MARINER)	1	1
2		73786	KNOB, FRONT COVER (MARINE	1	
3	12	30771	WASHER, COVER KNOB (RUBE	2	
4	12	75246	WASHER, COVER KNOB (STEE	2	
5	24	30772	SPRING, TENSION -COVER KNI	1	
6	17	29077	ROLL PIN, TENSION SPRING T	1	
7		47341A 1	ROPE, STARTER (MARINER)	1	
8		76434	SEAL, SOUND ABSORBING (MA	2	
9		38674	BLANKET, SOUND ABSORBING	1	
10	2164	6394A 7	WRAP AROUND COWL (MARINE	1	1
11		46785A 1	COWL LATCH ASSEMBLY (MAF	2	
12		30413	HOOK, COWL LATCH (MARINEF	2	