



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	2114	7934	TOP COWL, MERCURY	1	1
2		93122A 1	RETAINER ASSEMBLY, TOP COV	1	
3	10	53167	SCREW, RETAINER TO TOP COV	1	
4	13	39107	LOCKWASHER, RETAINER SCRE	1	
5		76370	SHIELD, TOP COWL-REAR MERC	1	
6	10	48409	SCREW, SHIELD TO TOP COWL	3	
1	2162	6392F 4	TOP COWL MARINER	1	1
2		76440	RETAINER ASSEMBLY, TOP COV	1	
3	10	25299	SCREW, RETAINER TO TOP COV	1	
4	13	39107	LOCKWASHER,RETAINER SCRE	1	
5		76433	SHIELD, TOP COWL-REAR MARII	1	
6	10	48409	SCREW, SHIELD TO TOP COWL	3	
7		52739	HINGE,COWL LATCH-TOP COWL	1	
8		94918T	LEVER, COWL LATCH HINGE	1	
9	17	58998	PIN, COWL LATCH LEVCH TO HIT	1	
10		55455	HOOK, TOP COWL LTECH-REAR	1	
11	10	22956	SCREW, REAR HOOK TO TOP CC	2	
12	13	26992	LOCKWASHER, REAR HOOK SCF	2	
13		73401	FRAME, SUPPORT-TOP COWL	1	
14		37640	MOUNT, RUBBER-SUPPORT FRZ	1	
15	13	26993	LOCKWASHER,RUBBER MOUNT	1	
16	11	28770	NUT, RUBBER MOUNT	1	
17	10	37562	SCREW, SUPPORT FRAME TO FI	2	
18	13	26993	LOCKWASHER, SUPPORT FRAM	2	
19		90435	MOUNT, RUBBER-TOP COWL FR	3	
20	11	20184	NUT, RUBBER MOUNT (UPPER)	6	
21		52468	BRACKET, TOP COWL SUPPORT	1	
22		31014	MOUNT, RUBBER-REAR SUPPO	2	
23	13	26992	LOCKWASHER, RUBBER MOUN	2	
24	11	29598	NUT, RUBBER MOUNT	2	
25	10	37562	SCREW, REAR BRACKET TO FR	4	
26	13	26993	LOCKWASHER, REAR BRACKET	4	
27	10	37562	SCREW, REAR BRACKET TO BO	4	
28	13	26993	LOCKWASHER, REAR BRACKET	4	
29		99649T	FRAME, FRONT SUPPORT	1	
30	10	37562	SCREW, SILENCER COVER	2	
31	13	26993	LOCKWASHER, FRAME SCREW	2	
32		89590	COVER, SILENCER	1	
33	27	76168A 2	GASKET, SILENCER COVER	1	2
34	10	28638	SCREW, COVER TO FRONT SUP	2	