



Parts List					
Ref	Class	Part	Description	Qty	Footnote
2	1161	5940A 2	END CAP ASSEMBLY, UPPER	1	
3	26	41953	OIL SEAL	1	
4	25	47254	"O"RING	1	2
5	15	73644A 1	SHIM, END CAP TO CRANKCASE	AR	4
6	10	73169	SCREW, UPPER END CAP (1")	4	
7		43352	POINTER, TIMING	1	
8	10	98510	SCREW, TIMING POINTER(3/4")	1	
9	12	20533	WASHER, TIMING POINTER SCR	1	
10	1148	5410A 1	END CAP ASSEMBLY, LOWER	1	
11	26	41953	OIL SEAL	2	
12	25	32546	"O"RING	1	2
13	15	20085A 1	SHIM, END CAP TO CRANKCASE	AR	4
14	10	69034	SCREW, LOWER END CAP(1")	3	
15	27	73665	GASKET, WATER JACKET COVER	1	2
16		76198	COVER, WATER JACKET-CYLIND	1	
17	10	53167	SCREW, WATER JACKET COVER	16	
18	12	70132	WASHER, WATER JACKET COVER	16	
19	27	85498 1	GASKET, CYLINDER BLOCK TO E	1	2
20		73436	PLATE, BAFFLE	1	
21	27	85496 1	GASKET, BAFFLE PLATE TO EXH	1	2
22		78277A 1	COVER, EXHAUST MANIFOLD	1	
23	10	53576	SCREW, MANIFOLD COVER (1-1/	18	
24	1021	8340	COVER, CYLINDER BLOCK	1	
25	27	96171 1	GASKET, CYLINDER BLOCK COVE	1	2
26	10	69100	SCREW, CYLINDER BLOCK COVE	12	
27		73320 1	COVER, TRANSFER PORT-TOP	1	(TRIANGLE FUEL PUMP)
27		14429T	COVER, TRANSFER PORT-TOP	1	(SQUARE FUEL PUMP)
28		87872	COVER, TRANSFER PORT-BOTT	1	
29	27	73645	GASKET, TRANSFER PORT COVE	1	2
30	10	49668	SCREW, TRANSFER PORT COVE	14	
31		37440	BRACKET, MOUNT SUPPORT-CY	1	
32	10	35386	SCREW, BRACKET TO CYLINDEF	1	
33		46933A 3	GROUND STRAP ASEMBLY	2	EXHAUST COVER SCREW
34	10	62568	SCREW, GROUND STRAP (3/8")	2	
35	87	96829A 1	TEMPERATURE SWITCH ASSEM	1	
36		45915	TERMINAL BLOCK	1	
37	10	62568	SCREW, TERMINAL BLOCK (3/8")	1	
38	10	28192	SCREW, TERMINAL BLOCK (1/2")	1	