



4104

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		804128T	INTAKE VALVE	8		6
2		804129T	EXHAUST VALVE	8		6
3		804130	SEAT	16		6
4	26	804136	SEAL	8		6
5	26	804137	SEAL	8		6
6	24	804131	VALVE SPRING	16		6
7		804132	RETAINER	16		6
8	28	804135	COTTER VALVE	32		6
9		804138T	VALVE LIFTER	16		6
10	15	804607 1	ADJUSTING PAD	AR	(2.350)	6
10	15	804607 2	ADJUSTING PAD	AR	(2.375)	6
10	15	804607 3	ADJUSTING PAD	AR	(2.400)	6
10	15	804607 4	ADJUSTING PAD	AR	(2.425)	6
10	15	804607 5	ADJUSTING PAD	AR	(2.450)	6
10	15	804607 6	ADJUSTING PAD	AR	(2.475)	6
10	15	804607 7	ADJUSTING PAD	AR	(2.500)	6
10	15	804607 8	ADJUSTING PAD	AR	(2.525)	6
10	15	804607 9	ADJUSTING PAD	AR	(2.550)	6
10	15	804607 10	ADJUSTING PAD	AR	(2.575)	6
10	15	804607 11	ADJUSTING PAD	AR	(2.600)	6
10	15	804607 12	ADJUSTING PAD	AR	(2.625)	6
10	15	804607 13	ADJUSTING PAD	AR	(2.650)	6
10	15	804607 14	ADJUSTING PAD	AR	(2.675)	6
10	15	804607 15	ADJUSTING PAD	AR	(2.700)	6
10	15	804607 16	ADJUSTING PAD	AR	(2.725)	6
10	15	804607 17	ADJUSTING PAD	AR	(2.750)	6
10	15	804608	ADJUSTING PAD	AR	(2.775)	6
10	15	804608 10	ADJUSTING PAD	AR	(2.800)	6
10	15	804608 20	ADJUSTING PAD	AR	(2.825)	6
10	15	804608 30	ADJUSTING PAD	AR	(2.850)	6
10	15	804608 40	ADJUSTING PAD	AR	(2.875)	6
10	15	804608 50	ADJUSTING PAD	AR	(2.900)	6
10	15	804608 60	ADJUSTING PAD	AR	(2.925)	6
10	15	804608 70	ADJUSTING PAD	AR	(2.950)	6
10	15	804608 80	ADJUSTING PAD	AR	(2.975)	6
11	2407	804139T	CAMSHAFT	1		6
12	17	804141	PIN, Dowel	2		
13	2407	804140T	CAMSHAFT	1		6
14	26	804144	OIL SEAL	2		2,6
15	43	804142T	DRIVEN GEAR	2		
16	10	804143	BOLT, (M10 x 25)	2		