



15226

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		12020A	1 HANDLE ASSEMBLY, Steering Arm	1		
1		12020A	2 STEERING ARM, Gray	1		
-	22	74036	FITTING, Grease	1		
2		12018A	2 TUBE ASSEMBLY	1		
3		48414	HOUSING	1		
4		48519	PLATE	1		
5	27	48518	GASKET	1		
6	10	72169	SCREW, (10-24 X .50)	5		
6	10	812832	SCREW, (#10-16 x .500)	5		
7	54	12013	CLAMP	1		
8	10	40007112	NUT, (M5 x 40)	2		
9	11	816873	WING NUT	1		
10	87	823609A15	STOP SWITCH KIT, Throttle Hand	1		
11	87	823609A 5	STOP SWITCH, Design II, With	1		
12		NLA	No Longer Available, Stop Switch, I	1		
13	10	62568	SCREW, (#10-16 x .375)	1		
14		99589	GRIP	1		
15	54	64855	CLAMP	2		
16	10	812832	1 SCREW, (#10-16 x .600)	1		
17		78551	2 CONDUIT	1		
18		89566	1 GUIDE TUBE	1		
19		89578	BARREL	1		
20	10	824081	SET SCREW, (#10-32)	1		
21		12019	CABLE	1		
22		43433	GUIDE	1		
23		20007	ANCHOR	1		
24	10	20518	SET SCREW, (#8-32)	2		
25	10	823567105	SCREW, (M10 x 105)	1		
26		48416	CAP	1		
27	12	40023	19 WASHER	1		
28	12	12024	WASHER	1		
29	23	14601	SPACER	1		
30	23	812930A	1 BUSHING	2		
31	11	13914	NUT, (M10)	1		
38		68878A 6	ALARM HORN AND WIRE ASSEM	1		
39		68879	COVER	1		
40	10	40056107	SCREW, (M5 x 16)	2		