



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	3401	8718A	1 TRANSOM BRACKET (STARBOARD)	1		
2	3400	8716A	1 TRANSOM BRACKET (PORT) -ME	1		
1	3401	8718A	2 TRANSOM BRACKET (STARBOARD)	1		
2	3400	8716A	2 TRANSOM BRACKET (PORT) MAI	1		
3	22	98727	1 GREASE FITTING, PORT TRAN	1		
4	17	49930A	1 TILT PIN ASSEMBLY (NON-POWE	1		
5		99170A	1 TILT TUBE	1		
6	11	34862	1 NUT, TILT TUBE (1"-14)	1		
7	25	45711	2 "O" RING, TILT TUBE	2		
8	13	88750	2 WAVE WASHER, TILT TUBE	2		
9	11	56041	1 NUT, TILT TUBE (7/8-14)	1		
10	10	67755	1 BOLT, TRANSOM BRACKET TO T	4		
11	12	28421	4 WASHER, TRANSOM BRACKET	4		
12	11	91962	4 NUT, TRANSOM BRACKET BOLT	4		
13		99629A	2 LEVER ASSEMBLY, TILT LOCK	1		
14	13	99611	1 WAVE WASHER, TILT LEVER	1		
15	23	65830	2 BUSHING, TILT LEVER	2		
16		99633	1 KNOB, TILT LOCK LEVER	1		
17	17	99615	1 GROOVE PIN	1		
18	24	99622	1 SPRING	1		
19	17	99604	1 GROOVE PIN	1		
20	10	96930A	1 BOLT ASSEMBLY, TILT LOCK-PO	1		
21	11	23161	1 NUT, BOLT -POWER TRIM	1		