



9857

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
-		881315A03	VAPOR SEPARATOR ASSEMBLY	1		
1		881316001	COVER	1		
2		880888T01	REGULATOR, Pressure	1		
3	10	881326004	SCREW	2		
4	19	823865001	PLUG, Cap	1		
5	10	881326005	SCREW	6		
6		881327002	PLATE, Baffle	1		
7	10	881326003	SCREW	3		
8		881327001	PLATE, Baffle	1		
9	84	888237001	HARNES ASSEMBLY, Wire	1		
10	54	881530008	CLAMP	1		
11		881329001	VALVE, Needle	1		
12		881320001	FLOAT	1		
13	17	881321001	PIN, Float	1		
14	25	881322004	DAMPER	1		
15	23	881332004	COLLAR	1		
16		880889T02	FUEL PUMP ASSEMBLY	1		
17	35	881323001	FILTER	1		
18	54	881530006	CLAMP	1		
19	25	881322003	DAMPER	1		
20	27	881325001	GASKET	1		
21		881319001	BODY ASSEMBLY	1		
22	10	881326006	SCREW, Drain	1		
23	25	881318001	O-RING	1		
24	25	93101M	GROMMET	3		
25	23	881332005	COLLAR	3		