



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1334	3734	CARBURETOR ASSEMBLY, COMI	1	SERIAL 00000000-02721150	
1	1334	4115	CARBURETOR ASSEMBLY, COMI	1	SERIAL 02810637-09999999	
2	1399	110A 1	FLOAT ASSEMBLY	1		
3			PIN, FLOAT LEVER PINION	2		3
4			LEVER, FLOAT (LOWER)	1		3
5			LEVER, FLOAT (UPPER)	1		3
6	1399	1138	INLET NEEDLE, SEAT AND GA	1		3
7			GASKET, INLET SEAT	1		3,0
8			GASKET, FLOAT BOWL COVER	1		3,0
9	1399	1133	COVER, FLOAT BOWL	1		
10	10	52195	SCREW, FLOAT BOWL COVER	1		
11	10	52196	SCREW, FLOAD BOWL COVER	1		
12	13	52197	LOCKWASHER, FLOAT BOWL C	2		
13			GASKET, STRAINER COVER (L	1		3,0
14	1399	1754	SCREEN, FILTER	1		3
15			GASKET, STRAINER COVER (S	1		3,0
16	1399	3690	COVER, STRAINER	1		
17			GASKET, STRAINER COVER SC	1		3
18	10	22822	SCREW, STRAINER COVER	1		3
19	10	20847	SCREW, THROTTLE STOP LEV	1		3
20	1399	97	LEVER, THROTTLE STOP	1		
21	1399	1716	SHAFT, THROTTLE	1		
22			TUBE, IDLE	1		3
23			GASKET, IDLE TUBE	1		3,0
24			SCREW AND LOCKWASHER, TH	1		3
25	1399	3743	SHUTTER, THROTTLE	1		
26			WELCH PLUG, BODY CHANNEL	1		3
27			SPRING, THROTTLE SHAFT RE	1		3
28	10	28845	SCREW, PLUG - BODY CHANNE	1		
29			MAIN NOZZLE	1		3
30	10	23178	SCREW, PLUG - MAIN NOZZLE	1		
31	1399	4188	JET, MAIN FUEL (.035) - STAND	1	SERIAL 02810637-09999999	3
31	1399	3251	JET, MAIN FUEL (.034) - STAND	1	SERIAL 00000000-02721150	3
31	1399	3252	JET, MAIN FUEL (.032)	OPT		
31	1399	3810	JET, MAIN FUEL (.030)	OPT		
32			GASKET, MAIN FUEL JET	1		3,0
33			GASKET, JET CHANNEL PLUG	1		3,0
34	10	28405	SCREW, PLUG - MAIN FUEL JE	1		
35	1399	3742	SCREW, IDLE ADJUSTMENT	1		3
36			SPRING, IDLE ADJUSTMENT S	1		3
	1399	1717	GASKET AND PACKING SET	1		2