



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	608	2646A	CONNECTING ROD ASSEMBLY	2		
2	10	39154	SCREW, CONNECTING ROD	4		
3	29	26815	BEARING, NEEDLE - CRANKPIN	58		
4	11	20061	NUT, CONNECTING ROD SCRE	4		
5	12	31433	WASHER, NEEDLE BEARING R	4		
6	29	31505	BEARING, NEEDLE - PISTON PI	40		
7	719	3374A	PISTON AND PISTON PIN ASSEM	2		
8	40	21666	LOCK RING, PISTON PIN	4		
9	39	21665A12	RING, PISTON	1		