



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	339	5209A	3 STATOR ASSEMBLY	1		
2	10	66707	SCREW, STATOR TO END CAP (;	3		
3	10	35400	SCREW, STATOR TO END CAP (;	1		
4	339	6119A	1 COIL ASSEMBLY (5 1/2" AND 6 3.	1		
4	339	6120A	1 COIL ASSEMBLY (1 3/4" AND 3 1.	1		
5	54	59538	CLIP, COIL RETAINING	2		
6	54	65927	CLIP, COIL RETAINING	2		
7	86	74474	TERMINAL BLOCK, STATOR	1		
8	10	20646	SCREW, TERMINAL BLOCK TO S	1		
9	11	46438	NUT, TERMINAL BLOCK SCREW	1		
11	338	5286A	6 TRIGGER HOUSING ASSEMBLY	1		
14		66371	LINK, TRIGGER HOUSING TO TH	1		
15	11	65110	NUT, PUSH - LINK TO TRIGGER	1		
16	339	5287A	4 SWITCH BOX	1		
17	10	69022	SCREW, SWITCH ATTACHING (1	2		
18	12	56681	WASHER, SWITCH BOX ATTACH	2		
19		61990	5 STA-STRAP	5		
20	10	45218	SCREW, GROUND LEAD TO CYL	1		