



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	2148	5180	COWL, BOTTOM	1	UNITED STATES 3801458 THRL	
1	2148	5569	COWL, BOTTOM	1	UNITED STATES 4085865 THRL	
1	2159	6107A 4	COWL, BOTTOM	1	UNITED STATES 4397537 AND I	
1A		74360	PLUG, BOTTOM COWL(MANUAL)	1		
2		39778	GROMMET, CHOKE SHAFT _ BO	1		
3		66353	COVER, ACCESS HOLE	1		
4		65479	COVER, ACCESS HOLE	1		
5		39474	ANCHOR, LATCH - BOTTOM COW	1		
6	10	22483	SCREW, LATCH ANCHOR TO BO	2		
7	13	26992	LOCKWASHER, LATCH ANCHOR	2		
8	12	36554	WASHER, NYLON - WATER OUT	1		
9	26	36556	SEAL, RUBBER - WATER OUTLE	1		4
10	10	38111	SCREW, BOTTOM COWL TO DRI	1		
11	13	26992	LOCKWASHER, BOTTOM COWL	1		
12	27	45748	GASKET, POWERHEAD TO ADAF	1		4
13		65478	LEVER, COWL LATCH	1	UNITED STATES 3801458 THRL	
13		74349	LEVER, COWL LATCH	1	UNITED STATES 4397537 AND I	
14		65613	CABLE, COWL LATCH	1		
15	10	65554	SCREW, COWL LATCH CABLE	1		
15A	12	56681	WASHER, COWL LATCH CABLE	2		
16	24	65520	SPRING, CABLE TO ARM LATCH	1		
17		69153	LATCH, ARM - BOTTOM COWL	1	UNITED STATES 3801458 THRL	
17		72791	LATCH, ARM - BOTTOM COWL	1	UNITED STATES 4314385 AND I	
18	29	52168	PIN, ARM LOCATING	1		
19		69154	LATCH, BODY - BOTTOM COWL	1		
19A	12	34680	WASHER, BODY LATCH	1		
20	10	32228	SCREW, LATCH TO BOTTOM CO	3		
21	27	39050	GASKET, BOTTOM COWL TO DR	1		4
22		59065A 4	STOP SWITCH ASSEMBLY	1	UNITED STATES 3801458 THRL	
23	24	60239	SPRING, STOP SWITCH	1	UNITED STATES 3801458 THRL	
24		38950A 1	COVER ASSEMBLY, STOP SWITC	1	UNITED STATES 3801458 THRL	
25	12	59061	WASHER, STATOR LEAD TO ST	1	UNITED STATES 3801458 THRL	
26	13	21972	LOCKWASHER, STOP SWITCH C	1	UNITED STATES 3801458 THRL	
27	11	21971	NUT, STOP SWITCH TO BOTTO	1	UNITED STATES 3801458 THRL	
29	13	68219	NUT, CONNECTOR BASE TO BO	1	UNITED STATES 3801458 THRL	
30	87	69508A 1	STOP SWITCH ASSEMBLY	1	UNITED STATES 4131610 AND I	
31	13	69845	LOCKWASHER, STOP SWITCH	1	UNITED STATES 4131610 AND I	
32	11	69844	NUT, STOP SWITCH	1	UNITED STATES 4131610 AND I	