

Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		835385T01	INTAKE MANIFOLD	1	
2	27	853525001	GASKET	1	2
3	18	815026	COTTER PIN	2	
4	10	853531001	BOLT	6	
5	12	895106	WASHER	6	
6	54	95395	CLAMP	1	
7	27	835383001	INSULATOR, Carburetor	2	2
8		853526001	INSULATOR	1	
9		835386001	AIR BOX	1	
10	25	825057003	O-RING	1	2
11	10	855809	BOLT, (M6 x 100)	2	
12	12	895106	WASHER	2	
13	32	851848004	HOSE, Breather	1	
14		803529T03	FUEL PUMP	1	
15	21	851812003	CHECK VALVE, (Black)	1	7
16	21	851812004	CHECK VALVE, (white)	1	7
17	27	855569003	GASKET	1	7
18		853731003	DIAPHRAGM	1	7
19	10	895107	SCREW	2	
20	10	895107001	SCREW	4	
21	25	803513	O-RING	1	2
22	10	855544	SCREW, (M6 x 25)	2	SN# 0R052327 & Below
22	10	855544021	SCREW	2	SN# 0R052328 & Up
23	32	851848005	HOSE, Fuel	1	
24	32	851848006	HOSE, Fuel	1	
25	35	16248	FILTER, Fuel	1	
26	54	95395	CLIP	4	
27	32	895108	PROTECTIVE TUBING	2	
28	32	895108001	PROTECTIVE SLEEVE	1	(Electric Remote Control)
29	32	895109	HOSE, Overflow	1	
-	27	835427A04	POWERHEAD GASKET SET	1	
-	21	851812A01	DIAPHRAGM KIT	1	

