



5685

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		803716A	2 RECOIL STARTER ASSEMBLY	1		
2		803716	2 STARTER HOUSING	1		
3	24	812645T	1 SPRING SET, Starter	1		
4		812633	1 STARTER SHEEVE	1		
5	24	812634	2 RETURN SPRING	2		
6		812635	2 RATCHET	2		
7	24	812636	1 FRICTION SPRING	1		
8	10	812637	1 BOLT	1		
9		812638	1 FRICTION PLATE	1		
10	50	12066A	9 ROPE	1		
11		812640	1 STARTER HANDLE	1		
12	25	812641	1 RETAINER	1		
13		16110	1 SEAL PLATE	1		
14		812642	1 STARTER PULLEY	1		
15	10	16828	1 SCREW, (with Lockwasher)	3		
16		17634	1 STARTER LOCK	1		
17	10	855544	9 SCREW	1		
18	23	17637	1 COLLAR	1		
19	24	17638	1 SPRING	1		
20		803721	1 CAM	1		
21	13	17641	1 WAVE WASHER	1		
22	10	855544	1 SCREW	1		
23		804891	2 ROD SNAP	2		
24		803681	5 STARTER LOCK ROD	1		
25	10	16705	3 BOLT	3		
26	13	40025	3 LOCKWASHER, (M6)	3		
27		804900	1 STARTER BRACKET	1	(Port)	
28		804900	2 STARTER BRACKET	1	(Starboard)	
29	10	16828	2 BOLT	4		
30	54	813275	1 CLAMP	1		
31	23	855545	1 COLLAR	1		