



15151

			Parts List			
Ref	Class	Part	Description	Qty	Comment	Footnote
1	2188	9006A 2	COWL ASSEMBLY, Port, Black	1		
1	2188	9006A 3	COWL ASSEMBLY, Port, Gray	1		
1	2188	9006A 4	COWL ASSEMBLY, Port, Oyster	1		
2		42940 4	SEAL, Upper Cowl	3		
3		12401	SEAL, Cowl, Rear	1		
4		90274	SEAL	1		
5		42958	SHIELD, Air Inlet, Black, Gray	1		
5		42958 1	SHIELD OYSTER, Air Inlet, Oyste	1		
6	10	48409	SCREW, (#10-16 x .625), Shield	3		
7	12	40022 13	WASHER, Shield Screw	3		
8		43533 1	SOUND BLANKET	1		
9		19368 2	SEAL, (4.20 Inch), Black, Gray	1		
9		19368 1	SEAL, (3.20 Inch), Oyster	1		
10	2187	9070A 4	COWL ASSEMBLY, Starboard, Blai	1		
10	2187	9070A 5	COWL ASSEMBLY, Starboard, Gra	1		
10	2187	9070A 3	COWL ASSEMBLY, Starboard, Oys	1		
11		11315A 1	OIL LEVEL GAUGE ASSEMBLY	1		
12	11	11316	SPEED/NUT	1		
12A		11317	RETAINER	1		
13	10	48409	SCREW, (#10-16 x .625), Shield	3		
14	12	40022 13	WASHER, Shield Screw	3		
15		43534 2	SOUND BLANKET, Black, Gray	1		
16		19368 2	SEAL, (4.20 Inch), Black, Gray	1		
16		19368 1	SEAL, (3.20 Inch), Oyster	1		
17		42905	GROMMET, Handle Models	1		
18		812431	PLUG, Handle Models	1		
19	26	60297	SEAL	1		
20		42957	SHIELD, Air Inlet	1		
21		47341A 1	EMERGENCY STARTER ROPE, b	1		
22		43138A 2	COVER ASSEMBLY MERCURY, B	1		
22		43138A 3	COVER ASSEMBLY MARINER, Gr	1		
22		43138A 5	COVER ASSEMBLY, Oyster	1		
23		12356	BUMPER	1		
24	24	17288	SPRING, Cover	1		
25		43137A 1	BRACKET ASSEMBLY	1		
26	11	43418 1	SPEED NUT	3		
27		15432	RETAINER, Bracket	1		
28	17	43134	PIN, Bracket	2		
29	10	48409	SCREW, (#10-16 x .625)	4		
30	12	53705	WASHER	4		
31		87985	BRACKET, Lower	2		