



				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
1	2188	9006A 2	COWL ASSEMBLY, PORT (MERC)	1		
1	2188	9006A 3	COWL ASSEMBLY, PORT (MARIN	1		
2		42940 4	SEAL, UPPER COWL	3		
3		12401	SEAL, COWL (REAR)	1		
4		90274	SEAL	1		
5		42958	SHIELD, AIR INLET	1		
6	10	48409	SCREW, SHIELD	3		
7	12	40022 13	WASHER, SHIELD SCREW	3		
8		43533 1	SOUND BLANKET	1		
9	2187	9070A 1	COWL ASSEMBLY, STARBOARD	1		
9	2187	9070A 2	COWL ASSEMBLY, STARBOARD	1		
9	2187	9005A 1	COWL ASSEMBLY, STARBOARD	1	HANDLE MODELS	
9	2187	9005A 2	COWL ASSEMBLY, STARBOARD	1	HANDLE MODELS	
10	26	60297	SEAL	1		
11		11315A 1	OIL LEVEL GAUGE ASSEMBLY	1		
12		42957	SHIELD, AIR INLET	1		
13	10	48409	SCREW, SHIELD	3		
14	12	40022 13	WASHER, SHIELD SCREW	3		
15		43534 2	SOUND BLANKET	1		
16		87985	BRACKET (LOWER)	2		
17		87987	BRACKET (UPPER)	2		
18	10	40095 25	SCREW, BRACKET	8		
19		12081	COWL LATCH	1		
20	10	48409	SCREW, LATCH	3		
21		47341A 1	STARTER ROPE ASSEMBLY (MA	1		
22		43138A 2	COVER ASSEMBLY MERCURY	1		
22		43138A 3	COVER ASSEMBLY MARINER	1		
23		12356	BUMPER	1		
24	24	17288	SPRING, COVER	1		
25		43137A 1	BRACKET ASSEMBLY	1		
26	11	43418 1	SPEED NUT	3		
27		15432	RETAINER, BRACKET	1		
28	17	43134	PIN, BRACKET	2		
29	10	48409	SCREW	4		
30	12	53705	WASHER	4		