



| Parts List | | | | | | |
|------------|-------|----------|-----------------------------|-----|--------------------------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | | 42968T | PLATE, IGNITION | 1 | | |
| 2 | 332 | 7778A 3 | SWITCH BOX ASSEMBLY | 1 | | |
| 3 | 10 | 69079 | SCREW, SWITCH BOX | 1 | | |
| 4 | 10 | 40007110 | SCREW, SWITCH BOX | 2 | | |
| 5 | 23 | 94304 | BUSHING, SWITCH BOX SCREW | 2 | | |
| 6 | 11 | 45076 | NUT, SWITCH BOX TERMINAL | 9 | | |
| 7 | 84 | 41592A 4 | HARNESS ASSEMBLY, PRIMARY | 1 | | |
| 8 | 84 | 99215A25 | CABLE, HIGH TENSION | 3 | | |
| 9 | 85 | 63709A 1 | PROTECTOR, SPARK PLUG | 3 | | |
| 10 | 33 | 97182 | SPARK PLUG | 3 | | |
| 11 | 10 | 40113 25 | SCREW, IGNITION PLATE | 3 | | |
| 12 | 339 | 7370A13 | IGNITION COIL ASSEMBLY | 3 | | |
| 13 | 11 | 45076 | NUT, IGNITION COIL TERMINAL | 6 | | |
| 14 | | 43542 | COVER, IGNITION COIL | 1 | | |
| 15 | 10 | 40007114 | SCREW, IGNITION COIL COVER | 6 | | |
| 16 | 12 | 89302 | WASHER, COIL COVER SCREW | 6 | | |
| 17 | | 62351A 1 | RECTIFIER ASSEMBLY | 1 | | |
| 18 | 10 | 40056107 | SCREW, RECTIFIER | 2 | | |
| 19 | 11 | 45076 | NUT, RECTIFIER TERMINAL | 2 | | |
| 20 | | 58124A28 | MERCURY SWITCH ASSEMBLY | 1 | | |
| 21 | 10 | 40056107 | SCREW, MERCURY SWITCH | 1 | | |
| 22 | | 45315 | TERMINAL BLOCK | 2 | | |
| 23 | 10 | 48408 | SCREW, TERMINAL BLOCK | 4 | | |
| 24 | 84 | 41591A 3 | WIRING HARNESS ASSEMBLY, E | 1 | | |
| 25 | 88 | 79091 | FUSE (20 AMP) | 1 | | |
| 26 | 84 | 88439A 3 | BATTERY CABLE (POSITIVE) | 1 | | |
| 26 | 84 | 88439A 4 | BATTERY CABLE (NEGATIVE) | 1 | | |
| 27 | 89 | 96158 | STARTER SOLENOID | 1 | | |
| 28 | 10 | 40007106 | SCREW, STARTER SOLENOID | 2 | | |
| 29 | 12 | 40023 14 | WASHER, STARTER SOLENOID | 2 | | |
| 30 | 84 | 88807A 6 | WIRE, SOLENOID SCREW (BLAC | 1 | | |
| 31 | 13 | 26992 | LOCKWASHER | 2 | STARTER SOLENOID TERMINA | |
| 32 | 11 | 64015 | NUT, STARTER SOLENOID TERM | 2 | | |
| 33 | 11 | 26419 | NUT, STARTER SOLENOID TERM | 2 | | |
| 34 | 84 | 88808A18 | WIRE, RECTIFIER TO SOLENOID | 1 | | |
| 35 | | 12417T | COVER, IGNITION | 1 | | |
| 36 | 10 | 40007114 | SCREW, IGNITION COVER | 3 | | |
| 37 | 12 | 89302 | WASHER, IGNITION COVER SCR | 3 | | |
| 38 | | 13473 1 | FUSE HOLDER | 1 | | |