



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	1255	8627A 5	OIL TANK	1	
2		99160	BOOT, OIL TANK (UPPER)	1	
3	87	44452A 1	TEST SWITCH ASSEMBLY	1	
4		44437	COVER, TEST SWITCH	1	
5		98895	BRACKET, OIL TANK (UPPER)	1	
6	10	40094 30	SCREW, OIL TANK BRACKET	2	
7	36	42653A 2	CAP ASSEMBLY, OIL TANK	1	
8	27	42999	GASKET, CAP	1	
9		93254	SWIVEL BASE	1	
10		93421	SWIVEL BALL	1	
11		43359	COWL ROD	1	
12	54	43406	CAMP, COWL ROD	1	
13	10	26548	SCREW, CLAMP	1	
14	12	22887	WASHER, CLAMP SCREW	1	
15	10	12896	SCREW, SWITCH	1	
16	87	12886A 2	SWITCH ASSEMBLY, OIL TANK	1	
17		99161	BOOT, OIL TANK BASE	1	
18		42888	BASE, OIL TANK	1	
19	25	56291	GROMMET	1	
20	10	40113 50	SCREW, BASE	2	
21	32	43017 36	TUBING	3	
22	22	73318	TEE	1	
23		73498	STA-STRAP	AR	7
24		42959T	OIL PUMP	1	
25	25	62705	"O" RING, OIL PUMP	2	10
26		42945A 1	ADAPTOR ASSEMBLY, OIL PUMF	1	
27	43	43020 1	DRIVEN GEAR	1	
28	10	40093 40	SCREW, OIL PUMP	2	
29	32	43016 19	TUBING, OIL PUMP TO FUEL PUM	1	
-	27	43004A86	GASKET SET		