



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	4026	828354A11	TOP COWL ASSEMBLY	1	(BLACK)	
1	4026	828354A12	TOP COWL ASSEMBLY	1	(SILVER)	
1	4026	828354A13	TOP COWL ASSEMBLY	1	(TRACKER GRAPHITE GRAY)	
2		819813	BRACKET-COVER LATCH	1		
3		18173	BRACKET-ROLLER LATCH	1		
4	13	53166	LOCKWASHER	2		
5	10	90285	SCREW	2		
6		F481434	GUIDE	2		
7	11	91925	PUSH NUT	4		
8	10	822512	SCREW (3/4 IN.)	3		
9		823583A	SOUND BLANKET KIT	1		
10		821912A	TRAP DOOR	1	(BLACK)	
10		821912A	TRAP DOOR	1	(SILVER)	
10		821912A	TRAP DOOR	1	(TRACKER GRAPHITE GRAY)	
11		823967	SEAL-TRAP DOOR	1		
12	17	822055	HINGE PIN	1		
13	10	821045	SCREW	2		
14	12	40023	WASHER	2		
15		821875F	UPPER CAP	1	(BLACK)	
15		821875F	UPPER CAP	1	(SILVER)	
15		821875F	UPPER CAP	1	(TRACKER GRAPHITE GRAY)	
16	11	826833	NUT	2		
17		823960	CATCH	1		
18	10	812832	SCREW (1/2 IN.)	1		
19	19	823865	CAP PLUG	2		
20	10	821300	SCREW	4		
21		47341A11	STARTER ROPE (MANUAL STAR	1		