



| Parts List | | | | | | |
|------------|-------|----------|----------------------------|-----|---------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | 19 | 45907 | PLUG, FLYWHEEL | 1 | | |
| 2 | | 42956A | COVER ASSEMBLY, FLYWHEEL | 1 | | |
| 3 | | 79022 | MARKER, TIMING | 1 | | |
| 4 | 10 | 37572 | SCREW, TIMING MARKER | 2 | | |
| 5 | 12 | 72761 | WASHER, TIMING MARKER SC | 2 | | |
| 6 | 11 | 42979 | NUT, FLYWHEEL | 1 | | |
| 7 | 12 | 68229 | WASHER, FLYWHEEL | 1 | | |
| 8 | 261 | 9008A16 | FLYWHEEL ASSEMBLY | 1 | | |
| 9 | 398 | 8778A10 | STATOR ASSEMBLY | 1 | | |
| 10 | 10 | 40073 25 | SCREW, STATOR | 4 | | |
| 11 | | 99021A 3 | TRIGGER ASSEMBLY | 1 | | |
| 12 | 50 | 66015 | STARTER MOTOR | 1 | | |
| 13 | | 56703 | COLLAR, STARTER MOTOR | 2 | | |
| 14 | | 57247 | STOP, RUBBER-STARTER MOTC | 2 | | |
| 15 | 84 | 93388A 1 | WIRE, STARTER MOTOR TO PL | 1 | | |
| 16 | 10 | 69035 | SCREW, WIRE TO STARTER MO | 1 | | |
| 17 | 84 | 88439A20 | WIRE, STARTER MOTOR (BLACK | 1 | | |
| 18 | 13 | 26992 | LOCKWASHER, STARTER MOTO | 1 | | |
| 19 | 11 | 64015 | NUT, STARTER MOTOR TERMIN | 1 | | |