



| Parts List |       |       |                         |     |         |          |
|------------|-------|-------|-------------------------|-----|---------|----------|
| Ref        | Class | Part  | Description             | Qty | Comment | Footnote |
| -          | 50    | 66015 | STARTER MOTOR ASSEMBLY  | 1   |         |          |
| 1          |       | 90643 | DRIVE KIT               | 1   |         |          |
| 2          |       | 68575 | DRIVE ASSEMBLY          | 1   |         |          |
| 3          |       | 75660 | PLATE, DRIVE END        | 1   |         |          |
| 4          | 10    | 75385 | BOLT, THRU              | 2   |         |          |
| 6          |       | 75386 | ARMATURE                | 1   |         |          |
| 7          |       | 75384 | BRUSH SET               | 1   |         |          |
| 8          | 23    | 57387 | BUSHING, INSULATING     | 1   |         |          |
| 9          | 12    | 38013 | WASHER, INPUT STUD      | 1   |         |          |
| 10         | 13    | 26992 | LOCKWASHER, INPUT STUD  | 1   |         |          |
| 11         | 11    | 20890 | NUT, INPUT STUD         | 1   |         |          |
| 12         |       | 61787 | HOLDER, BRUSH           | 2   |         |          |
| 13         | 10    | 68586 | SCREW, BRUSH AND HOLDER | 2   |         |          |
| 14         |       | 75383 | END CAP, COMMUTATOR     | 1   |         |          |