



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	472	9001A 3	CRANKSHAFT ASSEMBLY	1		
2	30	43011	BALL BEARING (LOWER)	1		
3		78661 1	WEAR SLEEVE	1		
4	25	35126	O-RING	1		
5	39	818412A 4	RING ASSEMBLY	1		
6	28	91800	KEY	2		
7	43	43019A 1	DRIVER GEAR	1		
8	31	43013A 1	ROLLER BEARING ASSEMBLY (U	1		
9	26	43993	OIL SEAL	1		
10	25	F289683	O-RING	1		
11		42943A 1	ROLLER BEARING ASSEMBLY	2		
12	777	815965A 4	PISTON ASSEMBLY (STANDARD	3		
12	777	815965A 5	PISTON ASSEMBLY (.015 O.S.)	AR		7
12	777	815965A 6	PISTON ASSEMBLY (.030 O.S.)	AR		7
13	40	52035	LOCK RING	6		
14	39	96170A12	PISTON RING ASSEMBLY (STA	1		
14	39	96170A 3	PISTON RING ASSEMBLY (.015	AR		7
14	39	96170A 4	PISTON RING ASSEMBLY (.030	AR		7
15	646	818846A 3	CONNECTING ROD ASSEMBLY	3		
16	12	812876	WASHER	6		
17	29	818391	NEEDLE BEARING	87		
18	10	94320	SCREW	6		
19	31	816567A 1	ROLLER BEARING ASSEMBLY	3		