



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1352	3737	CARBURETOR ASSEMBLY, COMI	2	SERIAL 00000000-02991033	
1	1352	4440A 1	CARBURETOR ASSEMBLY, COMI	2	SERIAL 03051041-09999999	
2	1399	110A 1	FLOAT ASSEMBLY	2		
3			PIN, FLOAT LEVER PINION	4		3
4			LEVER, FLOAT (LOWER)	2		3
5			LEVER, FLOAT (UPPER)	2		3
6	1399	1473	INLET NEEDLE, SEAT AND GA	2	SERIAL 00000000-02991033	3
6	1395	4555	INLET NEEDLE, SEAT AND GA	2	SERIAL 03051041-09999999	3
7			GASKET, INLET SEAT	2		3
8			GASKET, FLOAT BOWL COVER	2		3
9	1399	1133	COVER, FLOAT BOWL	2	SERIAL 00000000-02991033	
9	1399	4559	COVER, FLOAT BOWL	2	SERIAL 03051041-09999999	
10	10	52195	SCREW, FLOAT BOWL COVER	2		
11	10	52196	SCREW, FLOAT BOWL COVER	2		
12	13	26995	LOCKWASHER, FLOAT BOWL C	4		
13			GASKET, STRAINER COVER (L	2		3
14	1399	3938	SCREEN, FILTER	2		
15			GASKET, STRAINER COVER (S	2		3
16	1399	1930	COVER, STRAINER (UPPER CA	1		
16	1399	3698	COVER, STRAINER-LOWER CA	1	SERIAL 00000000-02991033	
16	1399	3690	COVER, STRAINER-LOWER CA	1	SERIAL 03051041-09999999	
17			GASKET, STRAINER COVER SC	2		3
18	10	25822	SCREW, STRAINER COVER FA	2		3
19	10	20847	SCREW, THROTTLE STOP LEV	2		3
20	1399	97	LEVER, THROTTLE STOP	2	USED ON LOWER CARBURETO	
21	1399	3527	SHAFT, THROTTLE	2		
22			TUBE, IDLE	2		3
23	10	23178	SCREW, BODY (IDLE TUBE)	2	SERIAL 00000000-02991033	
23	1395	4540	SCREW, BODY (IDLE TUBE)	2	SERIAL 03051041-09999999	
24			GASKET, IDLE TUBE	2	SERIAL 00000000-02991033	3
25			SCREW AND LOCKWASHER, T	4		3
26	1399	3528	SHUTTER, THROTTLE	2		
27			SPRING, IDLE ADJUSTMENT S	2		3
28	1399	3515	SCREW, IDLE ADJUSTMENT	2		3
29	10	28405	SCREW, PLUG-MAIN FUEL JET	2	SERIAL 00000000-02991033	
29	1395	4541	SCREW, PLUG-MAIN FUEL JET	2	SERIAL 03051041-09999999	
30			GASKET, JET CHANNEL PLUG	2		3
31	1399	3796	JET, MAIN FUEL (.076)	OPT		
31	1399	3794	JET, MAIN FUEL (.074)-STANDA	2		3
31	1399	3795	JET, MAIN FUEL (.072)	OPT		
31	1399	3811	JET, MAIN FUEL (.070)	OPT		