



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		58888A 4	FUEL PUMP ASSEMBLY	1		
2	21	30430A 5	CHECK VALVE ASSEMBLY	1		
3		55278A 2	DIAPHRAGM KIT	1		1,2
4			GASKET, FUEL PUMP	2		1,2
5			GASKET, CHECK VALVE TO	2		1,2
6		23004	RETAINER, CHECK VALVE	1		
7	10	20037	SCREW, RETAINER TO HOUSII	2		
8	10	27281	SCREW, PUMP MOUNTING (1 3/4	3		
9	32	55827A 1	FUEL LINE ASSEMBLY, PUMP TC	1		
10	22	59351	ELBOW, UPPER CARBURETOR (1		
11	22	30175	SLEEVE, UPPER CARBURETOR (1		
12	22	30177	NUT, UPPER CARBURETOR ELB	1		
13	32	54578A 1	FUEL LINE, CARB. TO CARB. (5 1	1	SERIAL 00000000-02991033	
13	32	59352	FUEL LINE, CARB. TO CARB. (6 5	1	SERIAL 03051041-09999999	
14	22	29085	ELBOW, UPPER CARBURETOR (1	SERIAL 00000000-02991033	
15	22	32802	PLUG, BOTTOM FILTER COVER	1	SERIAL 00000000-02991033	
16	22	30468	CONNECTOR, FUEL PUMP	2		
17	22	30175	SLEEVE, CONNECTOR	1		
18	22	30177	NUT, CONNECTOR	1		
19	32	55829	FUEL LINE, ADAPTOR TO UPPEF	1		
20		30186	ADAPTOR, CHECK UNIT (FUEL LI	1		
21		30187	STEM, CHECK UNIT ADAPTOR	1		
22	24	30189	SPRING, ADAPTOR STEM	1		
23	25	20415	"O"RING, ADAPTOR STEM	1		1,2
24		30188	CUP WASHER, ADAPTOR	1		
25	10	31471	SCREW, ADAPTOR TO BOTTOM	1		
25	10	37990	SCREW, ADAPTOR TO BOTTOM	1		
26	11	46887	NUT, ADAPTOR FASTENING SCF	2		