



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	440	6647A 2	CRANKSHAFT ASSEMBLY	1	
2	30	62567	BALL BEARING, UPPER	1	
3	30	63742	BALL BEARING, LOWER	1	
4		54196A 6	CARRIER ASSEMBLY	1	
5		65800	PACKING, CARRIER	1	2
6	540	5266A 5	MAIN BEARING ASSEMBLY (VAL)	2	
7	17	20032	DOWEL PIN, MAIN BEARING	4	
8	10	45775	SCREW, MAIN BEARING CLAMP	4	
9	11	45774	NUT, MAIN BEARING CLAMPIN	4	
10	34	56007A 1	REED SET, MATCHED - MAIN B	2	
11	34	56008	REED STOP, MAIN BEARING R	8	
12	10	62204	SCREW, REED STOP MOUNTIN	20	
13	11	53153	NUT, REED STOP MOUNTING	20	
14	535	5397A 4	CENTER MAIN BEARING ASSEMBLY	1	
15	17	20032	DOWEL PIN, CENTER MAIN BE	2	
16	29	71422	NEEDLE BEARING	56	
17		26113	RACE, OUTER (PAIR)	1	
18	53	26933	SNAP RING, OUTER RACE CL	1	
19	10	22968	SCREW, CENTER MAIN BEARING	2	
20	11	20184	NUT, MAIN BEARING CLAMPIN	2	
21	17	47246	DOWEL PIN, STEPPED	1	
22	768	7435A 3	PISTON AND PISTON PIN ASSEMBLY	4	
22	768	7436A 2	PISTON AND PISTON PIN ASSEMBLY	AR	3
22	768	7455A 3	PISTON AND PISTON PIN ASSEMBLY	AR	3
23	40	52035	LOCK RING, PISTON PIN	8	
24	39	78816A12	PISTON RING (STANDARD)	1	
24	39	78811A12	PISTON RING (.015 O.S.)	1	
24	39	88392A12	PISTON RING (.030 O.S.)	1	
25	624	8101A 3	CONNECTING ROD AND CAP SCREW	4	
26	10	54803	SCREW, CONNECTING ROD	8	
27	11	49091	NUT, CONNECTING ROD SCREW	8	
26	10	91012	SCREW, CONNECTING ROD - VAL	8	
28	31	62596A 1	BEARING ASSEMBLY, CRANKPIN	4	
29	29	47270	NEEDLE BEARING, PISTON PIN	116	
30	12	47247	WASHER, NEEDLE LOCATING	8	
-	27	73645A32	GASKET SET		