



| Parts List | | | | | | |
|------------|-------|----------|-----------------------------|-----|---------------------------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| - | | 76395A 5 | HYDRAULIC PUMP ASSEMBLY, C | 1 | | |
| 1 | 25 | 48171 | "O" RING, HYDRAULIC PUMP | 4 | | |
| 2 | 392 | 2936 | VALVE BODY AND GEAR ASSE | 1 | | |
| 3 | 10 | 20411 | SCREW, VALVE BODY TO RESI | 8 | | |
| 4 | 392 | 2937 | SEAL, RESERVOIR TO VALVE E | 1 | | |
| 5 | 392 | 2939 | RESERVOIR ASSEMBLY | 1 | | |
| 6 | 10 | 38257 | SCREW, VENT - HYDRAULIC PI | 1 | | |
| 7 | 10 | 79953 | SCREW, FILLER - HYDRAULIC I | 1 | | |
| 8 | 12 | 20260 | WASHER, SEALING - FILLER SC | 1 | | |
| 9 | 392 | 2623 | WASHER, THRUST - ARMATUR | AR | | 3 |
| 10 | 392 | 2943 | ARMATURE, FIELD AND FRAMI | 1 | | |
| 11 | 392 | 2942 | FIELD AND FRAME ASSEMBLY | 1 | | |
| 12 | 392 | 2944 | BALL, COMMUTATOR END PLA | 1 | | |
| 13 | 392 | 2940 | PLATE ASSEMBLY, COMMUTA | 1 | | |
| 14 | 392 | 2941 | BRUSH SET, COMMUTATOR | 1 | | |
| 15 | 392 | 2529 | SPRING SET, BRUSH TENSION | 1 | | |
| 16 | 392 | 2938 | BOLT SET | 1 | THRU - PLATE AND FRAME TO | |
| 17 | 13 | 26996 | LOCKWASHER, THRU BOLT | 2 | | |