



| Parts List |       |          |                             |     |                             |          |
|------------|-------|----------|-----------------------------|-----|-----------------------------|----------|
| Ref        | Class | Part     | Description                 | Qty | Comment                     | Footnote |
| 1          |       | 98517A 2 | PLATE ASSEMBLY, EXHAUST EX  | 1   |                             |          |
| 2          | 23    | 27132    | BUSHING, NYLON - EXHAUST E  | 1   |                             |          |
| 3          | 17    | 23784    | DOWEL PIN, EXHAUST EXTEN    | 2   |                             |          |
| 4          |       | 37918    | SEAL, EXHAUST EXTENSION F   | 1   |                             |          |
| 5          |       | 99358    | STRIP, RETAINING - EXHAUST  | 1   |                             |          |
| 6          | 10    | 37571    | SCREW                       | 5   | SEAL AND RETAINING STRIP TI |          |
| 7          | 27    | 69238    | GASKET, POWERHEAD           | 1   |                             | 2        |
| 8          | 10    | 66023    | SCREW, ADAPTOR PLATE TO HO  | 2   |                             |          |
| 9          | 10    | 66023    | SCREW                       | 7   | HOUSING PLATE TO DRIVE SH   |          |
| 10         | 11    | 69254    | NUT, CRANKCASE STUDS        | 2   |                             |          |
| 11         | 12    | 25970    | WASHER, CRANKCASE STUDS     | 2   |                             |          |
| 12         | 27    | 66102    | GASKET, DRIVE SHAFT HOUSINI | 1   |                             | 2        |
| 13         | 26    | 60898    | SEAL, DRIVE SHAFT HOUSING P | 1   |                             |          |
| 14         |       | 98518A 4 | PLATE ASSEMBLY, DRIVE SHAF  | 1   |                             |          |
| 15         | 26    | 38970    | SEAL, RUBBER - WATER INLET  | 1   |                             | 2        |
| 16         | 17    | 23784    | DOWEL PIN, DRIVE SHAFT HOU! | 2   |                             |          |
| 17         | 27    | 69860    | GASKET, EXHAUST TUBE        | 1   |                             | 2        |
| 18         |       | 74199    | EXHAUST TUBE                | 1   |                             |          |
| 19         | 10    | 65414    | SCREW                       | 4   | EXHAUST TUBE TO DRIVE SHA   |          |
| 20         | 13    | 26992    | LOCKWASHER, EXHAUST TUBE    | 4   |                             |          |
| 21         | 12    | 25970    | WASHER, POWERHEAD STUDS     | 6   |                             |          |
| 22         | 11    | 34932    | NUT, POWERHEAD STUDS        | 6   |                             |          |
| -          | 27    | 73645A32 | GASKET SET                  |     |                             |          |