



| Parts List | | | | | | |
|------------|-------|----------|------------------------------|-----|-----------------------------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | 2104 | 5642A 8 | FRONT COVER ASSY (W/O DEC) | 1 | UNITED STATES 5824647 AND I | |
| 1 | 2182 | 7927A 8 | FRONT COVER ASSY (W/O DEC) | 1 | UNITED STATES 5824648 AND I | |
| 2 | | 73786 | KNOB, FRONT COVER | 1 | UNITED STATES 5824647 AND I | |
| 2 | | 56849 | KNOB, FRONT COVER | 1 | UNITED STATES 5824648 AND I | |
| 3 | 12 | 30771 | WASHER, COVER KNOB (RUBER) | 2 | | |
| 4 | 12 | 75246 | WASHER, COVER KNOB (STEEL) | 2 | | |
| 5 | 24 | 32271 | SPRING, TENSION - COVER KNOB | 1 | | |
| 6 | 17 | 29077 | ROLL PIN, TENSION SPRING T | 1 | | |
| 7 | | 47341A 1 | ROPE, STARTER (FOR MANUAL) | 1 | | |
| 8 | | 71040 | SEAL, SOUND ABSORBING | 1 | UNITED STATES 5824647 AND I | |
| 9 | | 94923 | SEAL, SOUND ABSORBING | 2 | UNITED STATES 5824648 AND I | |
| 10 | | 38674 | BLANKET, SOUND ABSORBING | 1 | | |
| 11 | | 54143 | SEAL, SOUND - UPPER | 1 | UNITED STATES 5824647 AND I | |
| 12 | 2119 | 3248A16 | WRAP AROUND COWL ASSEMBLY | 1 | (WITHOUT DECALS) | |
| 13 | | 46785A 1 | COWL LATCH ASSEMBLY | 2 | | |
| 14 | | 30413 | HOOK, COWL LATCH | 2 | | |