



| Parts List |       |          |                              |     |                           |          |
|------------|-------|----------|------------------------------|-----|---------------------------|----------|
| Ref        | Class | Part     | Description                  | Qty | Comment                   | Footnote |
| 1          |       | 73434A   | FUEL PUMP ASSEMBLY           | 1   |                           |          |
| 2          | 21    | 30430A   | CHECK VALVE ASSEMBLY         | 1   |                           |          |
| 3          |       | 55278A   | DIAPHRAGM ASSEMBLY           | 1   |                           | 5        |
| 4          |       |          | GASKET, CHECK VALVE          | 2   |                           | 5        |
| 5          |       |          | GASKET, FUEL PUMP            | 2   |                           | 5        |
| 6          |       | 23004    | RETAINER, CHECK VALVE        | 1   |                           |          |
| 7          | 10    | 20037    | SCREW, CHECK VALVE TO FUE    | 2   |                           |          |
| 8          | 35    | 73532    | FUEL FILTER                  | 1   |                           | 5        |
| 9          | 25    | 47386    | "O" RING, COVER TO FUEL PU   | 1   |                           | 5        |
| 10         |       | 77885    | COVER, FUEL PUMP             | 1   |                           |          |
| 11         | 10    | 37370    | SCREW, COVER TO FUEL PUM     | 1   |                           |          |
| 12         | 27    | 25848    | GASKET, COVER SCREW          | 1   |                           | 5        |
| 13         | 10    | 70939    | SCREW                        | 1   | FUEL PUMP TO UPPER TRANSF |          |
| 13         | 10    | 27281    | SCREW                        | 2   | FUEL PUMP TO UPPER TRANSF |          |
| 14         | 22    | 64705    | FITTING, FUEL PUMP (OUTLET   | 1   |                           |          |
| 15         | 32    | 63146    | FUEL LINE, TEE TO FUEL PUMP  | 1   |                           |          |
| 16         | 22    | 73318    | TEE, FUEL LINE               | 1   |                           |          |
| 17         | 32    | 63146    | FUEL LINE                    | 2   | CARBURETOR TO TEE TO CARI |          |
| 18         | 54    | 68424    | CLAMP, FUEL LINE ATTACHING   | 8   |                           |          |
| 19         | 32    | 70432    | FUEL LINE, ADAPTOR TO FUEL F | 1   |                           |          |
| 20         | 22    | 63187    | FITTING, FUEL LINE TO ADAPTO | 1   |                           |          |
| 21         |       | 22833    | ADAPTOR, CHECK UNIT (FUEL LI | 1   |                           |          |
| 22         |       | 23069    | STEM, CHECK UNIT ADAPTOR     | 1   |                           |          |
| 23         | 25    | 20415    | "O" RING, ADAPTOR STEM       | 1   |                           | 5        |
| 24         | 24    | 23067    | SPRING, ADAPTOR STEM         | 1   |                           |          |
| 25         |       | 30188    | CUP WASHER, ADAPTOR          | 1   |                           |          |
| 26         | 10    | 69029    | SCREW, ADAPTOR TO BOTTOM     | 2   |                           |          |
| 27         | 11    | 36069    | NUT, ADAPTOR SCREW           | 2   |                           |          |
| --         | 27    | 73645A76 | GASKET SET                   |     |                           |          |