



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		29889	BRACKET, GUIDE RACK	1,1		
2	25	29727	GROMMET, GUIDE RACK BRACK	1,1		
3		26610A 6	GUIDE RACK ASSEMBLY	1,1		
4	10	24227	SCREW, THROTTLE STOP ADJU	1,1		
5	11	20890	NUT, THROTTLE STOP ADJUSTI	1,1		
6		26852	CAP, NYLON - ADJUSTING SCRE	1,1		
7	10	28636	SCREW, GUIDE RACK BRACKET	2,2		
8	12	20533	WASHER, GUIDE RACK BRACKET	2,2		
9		26827A 2	RACK AND PIN ASSEMBLY, GU	1,1		
10	17	29912	PIN, LINK - NYLON RACK	1,1		
11	17	23757	PIN, ROLL - LINK PIN TO NYLOI	1,1		
12		29891	LEVER, VERTICAL	1,1		
13		26593	LINK, VERTICAL LEVER TO NYLC	1,1		
14	17	26637	RIVERT, LINK TO VERTICAL LEV	1,1		
15	11	20110	NUT, LINK PIN TO VERTICAL LE	1,1		
16	23	26599	BUSHING, NYLON - VERTICAL LE	1,1		
17	23	26603	BUSHING, STEEL - VERTICAL LE	1,1		
18	23	26600	BUSHING, NYLON - VERTICAL LE	2,2		
19	10	26638	SCREW, VERTICAL LEVER TO E	1,1		
20	12	21040	WASHER, VERTICAL LEVER FAS	1,1		
21		30006	LEVER, REVERSE THROTTLE PI	1,1		
22	10	29155	SCREW, PICK-UP LEVER TO DIS	2,2		
23	12	20533	WASHER, PICK-UP LEVER FAS	2,2		
24		29156	LOCKWIRE, PICK-UP LEVER FAS	1,1		
25	393	1282A14	DISTRIBUTOR ASSEMBLY, COMF	1,1		
26	03	30578	SPARK PLUG (J4J)	6,6		
27	54	24836	CLIP, DISTRIBUTOR PRIMARY G	1,1		
28		22789	"D" WASHER, GROUND LEAD CI	1,1		
29	10	30009	SCREW, DISTRIBUTOR GROUND	1,1		
30		26433	COIL, IGNITION	2,2		
31	25	26543	"O" RING, IGNITION COIL	2,2		
32		28922	JUMPER, COIL TO COIL	1,1		
33		26514	BRACKET, COIL FASTENING	1,1		
34		26512	BAND, COIL BRACKET	1,1		
35	10	26889	SCREW, COIL BAND TO BRACKE	1,1		
36	11	20184	NUT, COIL BAND SCREW	1,1		
37	10	20784	SCREW, COIL BRACKET TO BOT	1,1		
38	10	26889	SCREW, COIL BRACKET TO BOT	1,1		
39	11	20184	NUT, COIL BRACKET SCREW	2,2		
40	16	20077	STUD, COIL BRACKET TO SUPP	1,1		
41		20228	SUPPORT, EXTERNAL WIRING	1,1		