



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	182	1809A 2	TOP COWL ASSEMBLY	1,	USE THRU SERIAL #1402843 OI	
2	16	20353	STUD, FRONT - TOP COWL TO	2,	USE THRU SERIAL #1402843 OI	
3	25	20116	GROMMET, CHOKE KNOB	1,	USE THRU SERIAL #1402843 OI	
1	182	1895A 2	TOP COWL ASSEMBLY	1,1	STARTED WITH SERIAL 140284	
2	16	20353	STUD, FRONT - TOP COWL TO	2,2	STARTED WITH SERIAL 140284	
3	25	20116	GROMMET, CHOKE KNOB	1,1	STARTED WITH SERIAL 140284	
-	37	46023A 1	DECAL, TOP COWL - STARBOA	1,1	STARTED WITH SERIAL 140284	
-	37	46023A 1	DECAL, TOP COWL-PORT SIDE	1,1	STARTED WITH SERIAL 140284	
4		31476	REVEAL, AIR INTAKE	1,1		
5	10	37370	SCREW, REVEAL TO TOP COWL	2,2		
6	13	26396	LOCKWASHER, REVEAL TO TOP	2,2		
7		31475	SCREEN, VENT - TOP COWL	1,1		
8	10	26668	SCREW, VENT SCREEN TO TOP	2,2		
9		29981A 1	PLATE ASSEMBLY - COWL MOUN	1,1		
10	16	20353	STUD, REAR - TOP COWL TO C	2,2		
11	10	29282	SCREW, PLATE ASSEMBLY TO T	3,		
11	10	28668	SCREW, PLATE ASSEMBLY TO T	,3		
--	37	46023A 1	LETTERS, SET - STARBOARD	1,	USE THRU SERIAL #1402843 OI	
12		29939M	LETTER "M" - STARBOARD	1,	USE THRU SERIAL #1402843 OI	
13		29939 E	LETTER "E" - STARBOARD	1,	USE THRU SERIAL #1402843 OI	
14		29939 R	LETTER "R" - STARBOARD	2,	USE THRU SERIAL #1402843 OI	
15		29939 C	LETTER "C" - STARBOARD	1,	USE THRU SERIAL #1402843 OI	
16		29939 U	LETTER "U" - STARBOARD	1,	USE THRU SERIAL #1402843 OI	
17		29939 Y	LETTER "Y" - STARBOARD	1,	USE THRU SERIAL #1402843 OI	
--	37	46023A 1	LETTERS, SET - PORT	1,	USE THRU SERIAL #1402843 OI	
12		29940M	LETTER "M" - PORT	1,	USE THRU SERIAL #1402843 OI	
13		29940 E	LETTER "E" - PORT	1,	USE THRU SERIAL #1402843 OI	
14		29940 R	LETTER "R" - PORT	2,	USE THRU SERIAL #1402843 OI	
15		29940 C	LETTER "C" - PORT	1,	USE THRU SERIAL #1402843 OI	
16		29940 U	LETTER "U" - PORT	1,	USE THRU SERIAL #1402843 OI	
17		29940 Y	LETTER "Y" - PORT	1,	USE THRU SERIAL #1402843 OI	
18	53	30022	FASTENER, LETTER TO TOP CO	28,	USE THRU SERIAL #1402843 OI	
19	12	20028	WASHER, TOP COWL STUD (1/1	4,4		
20	12	20346	WASHER, TOP COWL STUD (3/4	4,4		
21	12	20583	WASHER, TOP COWL STUD (1/3	AR,AR		
22	11	20361	NUT, TOP COWL FASTENING	4,4		
23		30755	RETAINER, STARTER SPRING	1,1		
24	24	30753	SPRING, STARTER REWING	1,1		
25	23	30754	BUSHING, SPRING GUIDE	1,1		
26	50	30749	SHEAVE ASSEMBLY	1,1		
27		20162	RAWL, STARTER	2,2		