



				Parts List			
Ref	Class	Part	Description	Qty	Comment	Footnote	
1	182	1680A 2	TOP COWL ASSEMBLY	1,1			
2	16	20353	STUD, FRONT - TOP COWL TO	2,2			
3		29980A 1	TRIM MOULDING ASSEMBLY -	1,1			
4	10	29226	SCREW, DECORATIVE - MOU	2,2			
4	10	29226	SCREW, DECORATIVE - MOU	2,2			
5	10	29227	SCREW, BRASS - MOULDING	2,2			
6	13	26995	LOCKWASHER, MOULDING F	4,4			
7	11	26419	NUT, MOULDING FASTENING	4,4			
8		30010	REVEAL, AIR INTAKE	1,1			
9	10	30405	SCREW, REVEAL TO TOP COW	2,2			
10	13	26996	LOCKWASHER, REVEAL TO TC	2,2			
11		29947	SCREEN, VENT - TOP COWL	1,1			
12	10	29221	SCREW, VENT SCREEN TO TO	2,2			
13		29981A 1	PLATE ASSEMBLY - COWL MOI	1,1			
14	16	20353	STUD, REAR - TO COWL TO	2,2			
15	10	29282	SCREW, PLATE ASSEMBLY TO	3,3			
--		29939	LETTERS, SET - STARBOARD (T)	1,1			
16		29939M	LETTER "M" - STARBOARD	1,1			
--		29939 E	LETTER "E" - STARBOARD	1,1			
18		29939 R	LETTER "R" - STARBOARD	2,2			
19		29939 C	LETTER "C" - STARBOARD	1,1			
20		29939 U	LETTER "U" - STARBOARD	1,1			
21		29939 Y	LETTER "Y" - STARBOARD	1,1			
--		29940	LETTER, SET - PORT (TOP COW)	1,1			
16		29940M	LETTER "M" - PORT	1,1			
17		29940 E	LETTER "E" - PORT	1,1			
18		29940 R	LETTER "R" - PORT	2,2			
19		29940 C	LETTER "C" - PORT	1,1			
20		29940 U	LETTER "U" - PORT	1,1			
21		29940 Y	LETTER "Y" - PORT	1,1			
22	53	30022	FASTENER, LETTER TO TOP CO	28,28			
23	12	20028	WASHER, TOP COWL STUD (1/1	4,4			
24	12	20346	WASHER, TOP COWL STUD (3/4	4,4			
25	12	20583	WASHER, TOP COWL STUD 9/16	AR,AR			
26	11	20361	NUT, TOP COWL FASTENING	4,4			
27		29938	HANDLE, CHROME - TOP COWL	1,1			
28		29946A 1	HANDLE, INSIDE - TOP COWL	1,1			
29		29413	BUTTON, BUMPER - TOP COWL	1,1			
30	12	29245	WASHER, CHROME HANDLE TO	1,1			
31	11	20586	NUT, CHROME HANDLE TO INSII	1,1			
32	10	29199	SCREW, FRONT - HANDLE TO TC	1,1			