



CLAMP AND SWIVEL BRACKET ASSEMBLY

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1440	3296A 1	CLAMP BRACKET ASSEMBLY	2,2		
2		28403A 3	THUMB SCREW ASSEMBLY	2,2		
3	12	28404	WASHER, THUMB SCREW	2,2		
4		30664	TUBE, TILT - CLAMP BRACKET T	1,1		
5	15	30497A 1	SHIM, CLAMP BRACKET TILT TU	2,2		
6	11	30499	NUT, TILT TUBE FASTENING	2,2		
7		53078	CAP, PLASTIC-TILT TUBE	2,2		
8	23	59624	SPACER, CLAMP BRACKET STUC	1,1		
9	16	59625	STUD, CLAMP BRACKET	1,1		
10	13	26993	LOCKWASHER, CLAMP BRACKET	2,2		
11	11	22053	NUT, CLAMP BRACKET STUD	2,2		
12	17	49930A 1	TILT LOCK PIN ASSEMBLY	1,1		
13	32	28052	SLEEVE, RUBBER - TILT LOCK PI	1,1		
14	1453	1814A 1	SWIVEL BRACKET ASSEMBLY	1,1		
15	22	69059	FITTING, GREASE	1,1		
16	26	32911	OIL SEAL	2,2		
17	24	94891	SPRING, COIL - SWIVEL BRACK	1,1		
18	17	28658	PIN, COIL SPRING MOUNTING	1,1		
19	19	77633	LUBRICAP, SWIVEL PIN GEAR FI	1,1		
20	23	28688	SPACER, RUBBER - COIL SPRINC	2,2		
21	17	25598	PIN, REVERSE LOCK SPRING AT	1,1		
22	17	30784A 1	SWIVEL PIN AND TOP YOKE ASE	1,1		
23		28203	BUMPER, TOP YOKE	1,1		
24	10	30453	BOLT, TOP YOKE TO UPPER MO	2,2		
24	10	49554	BOLT, TOP YOKE TO UPPER MO	,2		
25	11	34933	NUT, TOP YOKE BOLT FASTENIN	2,2		
26	12	25176	WASHER, SWIVEL PIN - LOWER	1,1		
27	12	30610	WASHER, RUBBER - UPPER SHI	1,		3
27A		30614	BOOT, RUBBER - UPPER SHIFT	1,		2
27A		31234	BOOT, RUBBER - UPPER SHIFT	,1		
28	12	30611	WASHER, NYLON - UPPER SHIF	1,1		
29	38	56267	SERIAL PLATE	1,1		
30	10	25612	SCREW, DRIVE - SERIAL PLATE	4,4		
31		28205T	STRAP STOP, DRIVE SHAFT HO	1,1		
32	10	28200	SCREW, STRAP STOP TO DRIVE	1,1		
33	11	25269	NUT, STRAP STOP FASTENING	1,1		
34		30451	YOKE, BOTTOM	1,1		
35	11	71956	NUT, SWIVEL PIN RETAINING	1,1		
36	24	29821	SPRING, REVERSE LOCK TENSIO	1,1		
37		26903A 4	REVERSE LOCK ASSEMBLY	1,1		
38		20208	SHAFT, REVERSE LOCK PIVOT	1,1		