



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	184	2043A 3	COWL FRONT COVER ASSEMBL	1,1		
2		26183A 5	EMBLEM, FRONT COVER	1,1		
3	10	29226	SCREW, BRACKET TO FRONT	2,2		
4	13	26395	LOCKWASHER, BRACKET FAS	2,2		
5	11	26419	NUT, BRACKET FASTENING SC	2,2		
6		29345	BUMPER, RUBBER - FRONT CC	2,2		
7		30769	KNOB, COWL FRONT COVER F.	1,1		
8	12	30771	WASHER, COVER FASTENING	1,1		
9	12	26825	WASHER, COVER FASTENING	2,2		
10	24	30772	SPRING, TENSION - FASTENIN	1,1		
11	17	29077	ROLL PIN, TENSION SPRING T	1,1		
12		30287	BLANKET, SOUND ABSORBING	1,		
12A		31089	STRIP, RUBBER - COWL FRON	,2		
13	2120	2509A 5	WRAP AROUND COWL ASSEMBL	1,1		
14		46785A 1	HANDLE, COWL LATCH	3,3		
15	53	21058	"E" RING, COWL LATCH HINGE	6,6		
16	17	21057	PIN, HINGE - COWL LATCH HAR	6,6		
17		46785A 1	SWIVEL, COWL LATCH	3,3		
18		30413	HOOK, COWL LATCH FASTENIN	3,3		
19		30021	BLANKET, SOUND ABSORBING	1,1		
--	92	25234 1	GLUE, ADHESIVE - BLANKET FAS	1,1		
--	92	27109 1	ADHESIVE COMPOUND (3 1/2 OZ)	1,1		