



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	1623	6053A37	GEAR HOUSING ASSY, COMP.(S	1	THE ENCLOSED GEAR HOUSIN	
-	1623	6053A23	GEAR HOUSING ASSY, COMP. (L	1	THE ENCLOSED GEAR HOUSIN	
-	1655	7333A27	GEAR HOUSING ASSY, COMP. (S	1	THE ENCLOSED GEAR HOUSIN	
-	1655	7333A25	GEAR HOUSING ASSY, COMP. (L	1	THE ENCLOSED GEAR HOUSIN	
1	1623	6053A 5	GEAR HOUSING ASSY	1	UNITED STATES 5141096 AND I	
1	1655	7333A23	GEAR HOUSING ASSY	1	UNITED STATES 5141097 AND I	
51		54346	CAM, SHIFT	1		
52		30625	FOLLOWER, CAM	1		
53		30624	SLIDE, CROSS PIN	1		
54	24	30622	SPRING, COMPRESSION-CAM F	1		
55	15	30923A 1	SHIM	AR	BEARING OUTER RACE TO GEA 6	
56	31	30894A 1	TAPERED ROLLER BEARING A	1		
57	31	30895	BEARING, ROLLER-FORWARD	1		
58	43	75314	FORWARD GEAR ASSEMBLY	1		
59	52	34239	RATCHET, SLIDING CLUTCH	1		
60	17	30632	PIN, CROSS-RATCHET TO PRO	1		
61	24	30893	SPRING, RETAINING-CROSS PI	1		
62	44	52542	SHAFT, PROPELLER	1		
63	43	77562	REVERSE GEAR ASSEMBLY	1		
65	12	76805	WASHER	1	THRUST-BEARING CARRIER TC	
67	25	29976	"O" RING, BEARING CARRIER	1		5
68		77520A 1	BEARING CARRIER ASSEMBLY	1		
69	31	30956	BEARING, ROLLER-BEARING	1		
70	26	76868	OIL SEAL, BEARING CARRIER	2		
71	28	30281	KEY,LOCATING-BEARING CARF	1		
72	14	52700	TAB WASHER, GEAR HOUSING	1		
73		52699	COVER, GEAR HOUSING	1		
74		31640A 1	TROM TAB, GEAR HOUSING	1		
75	10	66024	SCREW, TRIM TAB TO GEAR H	1		
76	12	45176	WASHER	2	GEAR HOUSING TO DRIVE SHA	
77	11	34933	NUT	2	GEAR HOUSING TO DRIVE SHA	
78	10	65210	SCREW	1	GEAR HOUSING TO DRIVE SHA	
79		75282	THRUST HUB	1		
82	14	31210	TAB WASHER, PROPELLER NU	1		
83	11	52707	NUT, PROPELLER	1		
--	27	73645A76	GASKET SET			